

CLEMAP Load Management Installation manual

Version 11.2022

CLEMAP Load Management Installation manual

Table of contents

CLEMAP Load Management Installation Instructions.....	Error! Bookmark not defined.
Material.....	2
Technical data.....	Error! Bookmark not defined.
Description.....	Error! Bookmark not defined.
Installation requirements.....	Error! Bookmark not defined.
Safety notice.....	Error! Bookmark not defined.
Power cable colours and their meaning.....	Error! Bookmark not defined.
Step 1: Electrical Installation.....	5
Step 2: CLEMAP connection to a WiFi network or via Ethernet cable.....	7
Step 3: Activation on cloud.clemap.com.....	9
Step 4: Integration of the charging stations, control and monitoring.....	9
Step 5: Integration of ripple control signal from power supply company.....	11

	As the installation takes place in the switch cabinet or in the fuse box, we recommend that you contact an electrician.
--	---

Material

Figure 1:
CLEMAP Load Management (a)



Figure 2:
3 current sensors, CT or Rogowski coils (b)



CLEMAP Load Management Installation manual

Technical data

Power supply:

230V+/-10% 50/60Hz AC

Conforms to EU standards:

- RE Directive 2014/53/EU
- LVD 2014/35/EU
- EMC 2014/30/EU
- RoHS2 2011/65/EU

Radio protocol:

WIFI 802.11b/g/n

LAN:

RJ45 connector **WIFI frequency:**

2.4 – 2.5 GHz **operating range**

(depending on local construction):

- up to 50 m outdoors
- up to 30 m indoors

Dimensions (WxHxD):

105 x 86 x 59 mm

Power consumption:

<3W

Mechanical interface:

DIN rail

Description

CLEMAP Load Management is used for dynamic power limitation of two or more electric charging stations in a garage or car park. The power consumption of the entire building is measured and the remaining available power for the charging stations is calculated and communicated in real time. The load management status can be monitored and controlled historically and in real time via the online portal *CLEMAP Floem*.

CLEMAP Load Management can operate in the local network and basically works perfectly even without an internet connection. However, a temporary internet connection is required during the installation phase. It is also recommended to install a permanent internet connection so that the status of the charging stations can be monitored remotely via *CLEMAP Floem* after commissioning.

CLEMAP Load Management is installed in a fuse box and must be connected to the power supply lines between the meter and the building. Usually there are three input lines in a building: the phase conductors (L1=brown, L2=black and L3=grey) and as output the neutral conductor (also called N=blue). The three current sensors must be connected to the three input lines.

Installation requirements

Before you start the installation, check that the following points are fulfilled:

1. you have a smartphone or laptop to activate the CLEMAP product.
2. there is enough space in the fuse box to install the CLEMAP product.
 - a. Yes → Go to step 3.
 - b. No → Check whether you can install CLEMAP next to the fuse box.
CLEMAP can also be installed in other fuse boxes. Continue to point 3.
3. Is there an Ethernet cable connection or possibly a WIFI network at the installation location of the CLEMAP product?
 - a. Yes → Start the installation.
 - b. No → Pull a LAN cable up to the CLEMAP sensor or install a WIFI repeater and continue with the installation.

Safety notice



For all work with electricity, safety is paramount. The lines of the area where work is being done must be **switched off "all poles"** before the work. The best way to do this is to switch off the corresponding fuse. But be careful: **All-pole** means that all conductors, i.e. the phase as well as the neutral conductor, are de-energised. To ensure this, the residual current circuit breaker (FI) should also be switched off. **In addition, the cables must be checked to ensure that they are current-free before touching them.**

Power cable colours and their meaning

The function of each conductor can be recognised by the respective colour of the power cable in a proper electrical installation. But be careful: Old buildings often have the wrong colouring of the conductors because the standards have changed several times over the years.

Basically, there are three types of electrical cables. First, there is the active conductor, the outer conductor, also called the phase conductor (L) or simply phase. Then there is the neutral conductor (N). And finally there is the protective conductor (PE), also simply called earth (not used when installing the CLEMAP product).

The following are the colours of the power cables:

Phase	L1, L2 and L3	brown, black, grey
Neutral	N	blue
Earth	PE	green-yellow

However, especially with older installations, do not assume that the colour scheme of the electrical installation is correct.

CLEMAP Load Management Installation manual

Step 1: Electrical installation



As the installation takes place in the fuse box, we recommend that you contact an electrician.




Figure 3: Typical installation of CLEMAP Load Management




Figure 4: Typical installation of CLEMAP Load Management with photovoltaics




Figure 5: Schematic of the CLEMAP installation in a fuse box of the building.



Figure 6: Current sensor. The arrow must follow in the direction of the current (to the consumers).




Figure 7: Rogowski coil. The direction of current is shown by the arrow.

CLEMAP Load Management Installation manual

- a. make sure that the power supply in the fuse box is disconnected.
- b. position the CLEMAP product (a) so that the current sensors (b) can be easily connected to the main input cables (L1, L2 and L3) (as shown in Fig. 2).
- c. Attach the CLEMAP product to the fuse box.
- d. Connect the current sensors (b) to the insulated incoming power lines (L1, L2 and L3), **making sure that the arrow shown in figure 3 points in the direction of the electrical loads.**
- e. connect the current sensors (b) to the CLEMAP product and make sure that the current sensors of the L1, L2 and L3 cables match the corresponding voltage inputs L1, L2 and L3.
- f. Connect the inputs N, L1, L2 and L3 to the corresponding voltage lines after fusing (maximum 16 A).
- g. Switch on the fuses and wait 3 minutes until the sensor is active.

POWER LED- feedback	
OFF	The CLEMAP product is currentless.
ON	The CLEMAP product is switched on.
STATUS LED feedback	
OFF	The CLEMAP product has no connection to a LAN or WIFI network, so it creates its own hotspot (see step 2 on the next page).
Flashing	The CLEMAP product is connected to a network. It is currently seeking communication with the Internet.
ON	The CLEMAP product is connected to a WIFI network and receives data from the Internet.

RESET button	
pressed between 3 and 10 seconds	Restart The CLEMAP product is restarted.
pressed for more than 10 seconds	Reset saved WIFI The saved WIFI is deleted and the CLEMAP product creates a new hotspot.

CLEMAP Load Management Installation manual

Step 2: CLEMAP connection to a WIFI network or via Ethernet cable

- a. Connect to the WiFi network created by the CLEMAP product with your smartphone or laptop. ((Name: clemapXX, where XX = the last two digits of the serial number, Password: sensorsetup). **WARNING:** If an Ethernet cable is connected to the CLEMAP sensor, the clemapXX's WIFI hotspot is automatically deactivated.
- b. go to <http://192.168.1.100:4000>, via a browser, if the sensor is connected with an Ethernet cable, the IP may be different.




Figure 8




Figure 9




Figure 10


- c. Registration with
 - User: clemap
 - Password: The serial number on the housing (e.g. SE12345678)
- d. briefly check if the displayed consumption values (P, V and I) for the three phases L1, L2 and L3 are realistic. In case of anomalies, check if each current sensor matches the correct voltage phase, if the current sensors are connected to the correct input (main) cable and if they "clicked" when closed
- e. In the case of a **WiFi connection**, proceed to the next step. In the case of an **Ethernet connection**, connect the cable and go directly to step 3.
- f. Select Wifi Settings, choose your WiFi network from the pop-up menu and enter your WiFi password.
CAUTION: the CLEMAP product only supports WIFI on the 2.4 GHz band. Once you have saved the WIFI password, you can log out. Within a few minutes, the sensor will be connected to the WIFI network you have chosen.

CLEMAP Load Management Installation manual

Step 3: Activation on floem.clemap.com

Go to
<http://floem.clemap.com>

Figure 11



- Select Log In or Create an account (you will need the serial number and activation code that are included with these instructions).
- During the registration process you will receive a confirmation email, if you cannot find it, please check your spam folder.
- Follow the instructions. Then select under "Settings", "Metering Point Settings", "Activate new metering point".


Step 4: Integration of the charging stations, control and monitoring

On the portal <https://floem.clemap.com> you set the configuration of the charging stations under the menu item Load Management Setup.

Figure 12

Alternatively, the settings can also be configured via the local CLEMAP Load Management web server.

CLEMAP Load Management Installation manual



Select EV Charger Setup from the menu and configure the load management settings and the connections to the charging stations. For further instructions on how to install specific charging station models, see the table below.

Figure 13

Specific recommendations for supported charging stations:

Charging station make/model	Recommendations
All charging stations that are controlled via Modbus.	Switch off DHCP and set a fixed IP address. Make sure that the set IP address is part of the correct subnet and is not already used by another device.
ABB Terra	Leave DHCP switched on at the charging station and save a fixed IP address in the router.
Weidmüller AC Wallbox Business	<p>Leave DHCP switched on at the charging station and save a fixed Save IP address in the router.</p> <p>First set the IP address of the charging station.</p> <p>Restart the charging station: To ensure that the charging station restarts completely, wait at least 40 seconds before switching the power on again.</p> <p>Deactivating RFID authentication (DIP switch 10): Set DIP switch 10 to OFF only after you have set and accepted all other settings in the web interface as desired. All settings are only applied after a restart of the charge controller.</p>

CLEMAP Load Management Installation manual

Mennekes <i>AMTRON Professional+</i>	Leave DHCP switched on at the charging station and save a fixed IP address in the router. Setting « <i>Dynamic Load Management – DLM Master/Slave</i> » must be set to « <i>DLM Master (With internal DLM Slave)</i> ».
Webasto <i>Live</i>	Leave DHCP switched on at the charging station and save a fixed IP address in the router.
Zaptec <i>Pro and Home</i>	As the communication is from cloud to cloud, an internet connection is required.
Other models	Leave DHCP switched on at the charging station and save a fixed IP address in the router.

After completing the installation, it is possible to manage the installations via the *CLEMAP Floem* portal.




Figure 14

The following information is available in *CLEMAP Floem*:

- Status of the charging station: free, occupied, charging, discharging, not in operation
- With a CLEMAP Floem licence BASIC, you can dynamically control and adjust the limit of the charging stations in real time via the CLEMAP Floem portal.

Step 5 : Integration of ripple control signal from power supply company

CLEMAP Load Management supports external control signals, e.g. from the utility company.

- via digital input (24VDC)
- via the cloud via RestAPI interface

Supported modes are Normal, Reduced and Locked.

CLEMAP Load Management Installation manual




Figure 15: Lokale Anschluss des Rundsteuersignal

FAQ – Frequently asked questions

During installation, the CLEMAP product does not create a WIFI network with the name «clemapXX»:

If the sensor does not find a WIFI network to connect to, it goes into detection mode and makes its own WIFI network available (called “clemapXX”). It can take up to 3 minutes until “clemapXX” appears among the available networks. ATTENTION: When an Ethernet cable is connected to the CLEMAP product, the Clemap Nibble WiFi hotspot is automatically disabled.

The password for clemapXX WIFI network is not accepted:

After entering the clemapXX WIFI network password “sensorsetup”, it is not accepted. The network is set up, try again in 30 seconds.

I can't reach cloud.clemap.com through my browser:

Check the network connection. Check that you have selected the correct home WIFI and that you can reach the Internet (e.g. www.google.com). Try again later.

During the installation (step 2) I cannot reach 192.168.1.100:4000 via my browser:

Check whether you are connected to the “clemapXX” WIFI network or whether the LAN cable is plugged in. Refresh the webpage <http://192.168.1.100:4000> and wait up to 30 seconds. Check again that you are connected to the “clemapXX” WIFI network or that the LAN cable is plugged in and try to access the webpage <http://192.168.1.100:4000> again. If you still cannot access the webpage, try opening the webpage with another device, e.g. another mobile phone or computer. Perform a hard reboot by pressing the RESET button, e.g. with a screwdriver, for more than 3 seconds (see picture on next page) and wait 3 minutes.

During the installation (step 2) I cannot find my WIFI in the list of available networks:

Check whether the WIFI reaches the control cabinet in which the CLEMAP product is installed. If the WIFI router is too far away, install a LAN cable, a power line adapter (e.g. TP-LINK TL-WPA4220KIT) or a WIFI repeater. The sensor only supports WIFI networks on the 2.4 GHz frequency, if the network is on the 5 GHz frequency, activate transmission on 2.4 GHz via the menu of your WIFI router or install a repeater.

CLEMAP Load Management Installation manual

Ground fault circuit interrupter switches off

The RCD can compare the amount of current flowing in and out. If the sum is intact, the current flowing in must be as high as the current flowing back, whereby the sum of the currents of the neutral conductor and phases must be zero. If this is not the case, the RCD disconnects the circuit, it "pops out". If L1, L2 and/or L3 are connected after the RCD and the neutral is connected before it, the RCD will notice a difference between the current flowing back and forth. Make sure that L1, L2, L3 and the neutral are connected after the RCD.

The sensor cannot connect to the cloud (status LED flashes):

1. Check whether the ports TCP 443, 3032, 8883 and UDP 123 of the wireless router are open.
2. On the Sensor Setup page, blue screen (Installation, Step 2) perform a soft reboot by selecting "Reboot System" and wait 3 minutes.
3. Perform a hard restart by pressing the RESET button (see picture) and wait 3 minutes.
4. Some charging station models have their own DNS server which may interfere with the setup process. Plug charging stations into the router last so that the IP address is given by the router and not by the charging station.

Reboot System




Figure 16 Hard Reboot

I have installed the CLEMAP product correctly and registered it on the platform, but the data is not accessible on floem.clemap.com:

Check whether the sensor is communicating with <https://floem.clemap.com> by looking at the LED status on the sensor. If this flashes or is switched off, check whether the radio connection is also accessible when the control cabinet door is closed (install a repeater if necessary) and whether the router doors are open. → See question: **The sensor cannot connect to the cloud (status LED flashes)**. If the status LED is constantly lit, check at <https://floem.clemap.com> whether the measuring point is online. If this is not the case, please contact support.

Do you have any further questions about the installation? We will be happy to answer them at support@clemap.ch or by phone +41 44 548 20 61.