

Field Join Instructions BaseMat MB-300 and MB-400 Series

BaseMat MB-300 Series:

1. Use an H-2 (5/64") or a 5/64" Allen Wrench Hex Key.
2. Install the driver bit in the tip of a cordless hand drill, screw gun, or use the wrench for manual removal.
3. Locate the pre-drilled female receiving rail as well as the punched male hinge portion of the rail on the underside of the rails.
4. Slide rails together until the pre-drilled hole and punch line up.
5. Using the provided set screws, insert set screw into the lined up hole/punch to prevent sections from coming apart.

BaseMat MB-400 Series:

1. Use an H-3 (3/32") Hex Tip Bit Driver, or a 3/32" Allen Wrench Hex Key.
2. Install the driver bit in the tip of a cordless hand drill, screw gun, or use the wrench for manual removal.
3. Slide the hinged section of the mat into the female receiving rail.
4. Using the provided set screws, insert set screw into the end of the rail where the hinge was slid in to prevent sections from coming apart.