



How to retrofit Ezi-action® Coloured Ball Handles.



- Release the Safety Strap and pull up the Plunger.
- Remove the screw holding the white Ball Handle onto the Plunger.
- Pull off the white Ball Handle.
- Push coloured Ball Handle onto Plunger.
- Carefully align the holes on the coloured Ball Handle and Plunger.
- Replace the screw.
- Secure the Safety Strap.



THEY WORK AND KEEP WORKING