

Clearlight® Saunas International

Eco Varnish Application guide



Clearlight®

How to apply interior Eco varnish to your Clearlight® Sauna

Eco, or No-VOC (Volatile Organic Compounds) varnish requires a two coat process.

The varnish will last approximately five years and will give the wood protection from sweat stains and general wear and tear, making cleaning easier and prolonging the life of your wooden interior.

1 *This first step does NOT apply to new saunas

Lightly sand the bench, floor and wood heater guards using **150 grit** sandpaper. Just a light, quick sanding is all it needs. If there are any stains, you may want to give that area a little more attention before varnishing.

(Please note, we do not recommend varnishing heavily-stained wood, as perspiration can reappear through the varnish leaving undesirable, patchy blemishes.)

2 Apply the varnish to the bench, floor and heater guards using a brush.

3 Run the sauna for 2 hours at full temperature.

4 Lightly sand the sauna using the 150 grit sandpaper.

5 Reapply the varnish

6 Run the sauna one more time for 2 hours at full temperature.

