



Laundry recommendations



for Reflex Microfibre- and Ultra microfibre textiles

- > The washing machine must be intended for washing cleaning materials.
- > Sort the laundry; microfibre mopcloths and cloths are washed separately.
- > Use a detergent suitable for microfibre textiles. Dose by using dosing equipment.
- Always follow Rekola's instructions for temperature, washing program and tumble drying.
- > For clean, functional, and durable materials, service your machines regularly.

1. LOADING THE WASHING MACHINE



MAX LOAD MOPCLOTHS



MAX LOAD SURFACE CLOTHS



DON'T MIX CLOTH TYPES – WASH SEPARATELY!

2. PRE-RINSING PROGRAM



MINIMUM PRE-RINSING CYCLES



COLD WATER



NO DETERGENTS

3. MAIN PROGRAM



RECOMMENDED WATER LEVEL FULL LOAD



MAXIMUM WATER TEMPERATURE*

* in case of special hygiene requirements can thermal disinfection washing program be used. Ask your Rekola contact for advice.



NO BLEACH

DETERGENTS OVERDOSING may cause irreversible damage to fabric.

4. RINSING



MINIMUM RINSING CYCLES



WATER TEMPERATURE 1st cycle: 40° 2nc cycle 20° 3rd cycle: Cold



NO FABRIC SOFTENER

5. DRYING



40°
MAXIMUM
AIR TEMPERATURE



MAX LOAD CAPACITY Mopcloths must be able to fall freely. Avoid tunnel drying.