

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag 0033	mattnickel	38971-11	128	160	18	28	7316183897102	<b>63</b>
Handtag 0033	rostfri look	38974-11	128	160	18	28	7316183897409	<b>63</b>
Handtag 0033	svart	38973-11	128	160	18	28	7316183897300	<b>63</b>
Handtag 0112 Ara	alu-look	38791-11	96	113	9	35	7316183879108	<b>63</b>
Handtag 0112 Ara	alu-look	38792-11	128	145	9	35	7316183879207	<b>83</b>
Handtag 0140	mattnickel	3059-11	128	141	12	32	7316183059005	<b>76</b>
Handtag 0140	mattnickel	305903-11	192	205	12	32	7316183059036	<b>93</b>
Handtag 0143	krom	30591-11	128	137	9	28	7316183059104	<b>73</b>
Handtag 0143	rostfri look	30592-11	128	137	9	28	7316183059203	<b>73</b>
Handtag 0143	svart	305923-11	128	137	9	28	7316183059234	<b>67</b>
Handtag 0143	alu-look	305921-11	128	137	9	28	7316183059210	<b>73</b>
Handtag 0143	vit	305925-11	128	137	9	28	7316183059258	<b>67</b>
Handtag 0143	koppar	305926-11	128	137	9	28	7316183059265	<b>73</b>
Handtag 0143	mässing pol.	305919-11	128	137	9	28	7316183059197	<b>73</b>
Handtag 0143	borst mässing	305922-11	128	137	9	28	7316180003926	<b>121</b>
Handtag 0143	rostfri look	305927-11	192	201	9	28	7316183059272	<b>93</b>
Handtag 0143	krom	305928-11	192	201	9	28	7316183059289	<b>93</b>
Handtag 0143	svart	305929-11	192	201	9	28	7316183059296	<b>86</b>
Handtag 0143	borst mässing	305942-11	192	201	9	28	7316180003933	<b>152</b>
Handtag 0143	krom	30593-11	320	329	9	28	7316183059302	<b>126</b>
Handtag 0143	rostfri look	30594-11	320	329	9	28	7316183059401	<b>126</b>
Handtag 0143	alu-look	305941-11	320	329	9	28	7316183059418	<b>126</b>
Handtag 0143	svart	305943-11	320	329	9	28	7316183059432	<b>116</b>
Handtag 0143	vit	305945-11	320	329	9	28	7316183059456	<b>116</b>
Handtag 0143	rostfri look	305947-11	492	501	9	28	7316183059470	<b>294</b>
Handtag 0143	krom	305948-11	492	501	9	28	7316183059487	<b>264</b>
Handtag 0143	svart	305949-11	492	501	9	28	7316183059494	<b>258</b>
Handtag 0143	borst.mässing	305950-11	492	501	9	28	7316180012768	<b>315</b>
Handtag 0143 5-p	rostfri look	30592-15	128	137	9	28	7316185300556	<b>292</b>
Handtag 0143 5-p	svart	305923-15	128	137	9	28	7316185300563	<b>264</b>
Handtag 1353	förnicklad	3306-11	87	101	7	34	7316183306000	<b>44</b>
Handtag 1353	förnicklad	330696-11	96	110	7	34	7316183306963	<b>49</b>
Handtag 1353	förnicklad	33061-11	128	142	7	34	7316183306109	<b>70</b>
Handtag 1353	förnicklad	330640-11	192	207	7	34	7316180007627	<b>117</b>
Handtag 1353	svart	3311-11	87	101	7	34	7316183311004	<b>52</b>
Handtag 1353	svart	331196-11	96	110	7	34	7316183311967	<b>54</b>
Handtag 1353	mattsvart	330632-11	128	142	7	34	7316180007658	<b>83</b>
Handtag 1353	mattsvart	330642-11	192	207	7	34	7316180007641	<b>122</b>
Handtag 1353	vit	3308-11	87	101	7	34	7316183308004	<b>52</b>
Handtag 1353	vit	330896-11	96	110	7	34	7316183308967	<b>54</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag 1353	obeh.mässing	33001-11	96	110	7	34	7316183300107	<b>67</b>
Handtag 1353	obeh.mässing	33063-11	128	142	7	34	7316183306307	<b>110</b>
Handtag 1353	obeh.mässing	330643-11	192	207	7	34	7316180018449	<b>171</b>
Handtag 1353	pol.mässing	330096-11	96	110	7	34	7316183300961	<b>67</b>
Handtag 1353	pol.mässing	33062-11	128	142	7	34	7316183306208	<b>110</b>
Handtag 1353	mässing	330641-11	192	207	7	34	7316180007634	<b>171</b>
Handtag 1353 läderlindat	svart/svart	330703-11	96	110	7	34	7316180018227	<b>327</b>
Handtag 1353 läderlindat	svart/förnicklad	330710-11	96	110	7	34	7316183307106	<b>308</b>
Handtag 1353 läderlindat	svart/pol.mp	330711-11	96	110	7	34	7316183307113	<b>334</b>
Handtag 1353 läderlindat	svart/obeh.mp	330712-11	96	110	7	34	7316183307120	<b>327</b>
Handtag 1353 läderlindat	svart/svart	330714-11	128	142	7	34	7316180018234	<b>372</b>
Handtag 1353 läderlindat	svart/förnicklad	330715-11	128	142	7	34	7316183307151	<b>372</b>
Handtag 1353 läderlindat	svart/pol.mp	330716-11	128	142	7	34	7316183307168	<b>415</b>
Handtag 1353 läderlindat	svart/obeh.mp	330717-11	128	142	7	34	7316183307175	<b>404</b>
Handtag 1353 läderlindat	brun/förnicklad	330721-11	96	110	7	34	7316183307212	<b>308</b>
Handtag 1353 läderlindat	brun/pol.mp	330722-11	96	110	7	34	7316183307229	<b>334</b>
Handtag 1353 läderlindat	brun/obeh.mp	330723-11	96	110	7	34	7316183307236	<b>327</b>
Handtag 1353 läderlindat	brun/förnicklad	330725-11	128	142	7	34	7316183307250	<b>372</b>
Handtag 1353 läderlindat	brun/pol.mp	330726-11	128	142	7	34	7316183307267	<b>415</b>
Handtag 1353 läderlindat	brun/obeh.mp	330727-11	128	142	7	34	7316183307274	<b>404</b>
Handtag 1353 läderlindat	natur/förnicklad	330704-11	96	110	7	34	7316180013192	<b>289</b>
Handtag 1353 läderlindat	natur/förnicklad	330707-11	128	142	7	34	7316180013215	<b>349</b>
Handtag 1353 läderlindat	natur/pol.mp	330708-11	128	142	7	34	7316180013239	<b>389</b>
Handtag 1353 läderlindat	natur/pol.mp	330705-11	96	110	7	34	7316180013208	<b>314</b>
Handtag 1353 lädersvept	mässing/svart	330737-11	96	110	7	34	7316180006637	<b>223</b>
Handtag 1353 lädersvept	mässing/svart	330747-11	128	142	7	34	7316180006699	<b>267</b>
Handtag 1353 lädersvept	mässing/svart	330767-11	192	207	7	34	7316180007764	<b>386</b>
Handtag 1353 lädersvept	mässing/brunt	330736-11	96	110	7	34	7316180006620	<b>223</b>
Handtag 1353 lädersvept	mässing/brunt	330746-11	128	142	7	34	7316180006682	<b>267</b>
Handtag 1353 lädersvept	mässing/brunt	330766-11	192	207	7	34	7316180007740	<b>386</b>
Handtag 1353 lädersvept	mässing/natur	330735-11	96	110	7	34	7316180006613	<b>223</b>
Handtag 1353 lädersvept	mässing/natur	330745-11	128	142	7	34	7316180006675	<b>267</b>
Handtag 1353 lädersvept	mässing/natur	330765-11	192	207	7	34	7316180007726	<b>386</b>
Handtag 1353 lädersvept	förnicklad/svart	330732-11	96	110	7	34	7316180006606	<b>210</b>
Handtag 1353 lädersvept	förnicklad/svart	330742-11	128	142	7	34	7316180006668	<b>228</b>
Handtag 1353 lädersvept	förnicklad/natur	330760-11	192	207	7	34	7316180007665	<b>326</b>
Handtag 1353 lädersvept	förnicklad/brunt	330731-11	96	110	7	34	7316180006590	<b>210</b>
Handtag 1353 lädersvept	förnicklad/brunt	330741-11	128	142	7	34	7316180006651	<b>228</b>
Handtag 1353 lädersvept	förnicklad/brunt	330761-11	192	207	7	34	7316180007689	<b>326</b>
Handtag 1353 lädersvept	förnicklad/natur	330730-11	96	110	7	34	7316180006576	<b>210</b>
Handtag 1353 lädersvept	förnicklad/natur	330740-11	128	142	7	34	7316180006644	<b>228</b>
Handtag 1353 lädersvept	förnicklad/svart	330762-11	192	207	7	34	7316180007702	<b>326</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag 15063	tenn	3936-11	128	142	15	27	7316183936009	<b>109</b>
Handtag 1690	förnicklad	39711-11		120	15	27	7316183971109	<b>78</b>
Handtag 1690	mässing	39712-11		120	15	27	7316183971208	<b>78</b>
Handtag 21213	alu-look	32501-11	128	153	20	30	7316183250105	<b>63</b>
Handtag 21213	rostfri look	32502-11	128	153	20	30	7316183250204	<b>63</b>
Handtag 21213	krom	32503-11	128	153	20	30	7316183250303	<b>63</b>
Handtag 44324	rostfri look	3345-11	128	142	17	29	7316183345009	<b>49</b>
Handtag 5182 inkl Skruv	rostfritt stål	397959-11					7316183979594	<b>205</b>
Handtag 5182 inkl skruv	svart	397958-11		67	30	25	7316180013277	<b>190</b>
Handtag 7032	koppar	31814-11	96	126	13	25	7316183181409	<b>99</b>
Handtag 7032	tenn	31813-11	96	126	13	25	7316183181300	<b>49</b>
Handtag 7032	rostfri look	31810-11	96	126	13	25	7316183181003	<b>51</b>
Handtag 7032	rostfri look	31820-11	128	138	14	26	7316183182000	<b>74</b>
Handtag 7032	tenn	31823-11	128	138	14	26	7316183182307	<b>74</b>
Handtag 735	rostfri look	345426-11	96	104	27	12	7316183454268	<b>47</b>
Handtag 735	rostfri look	34543-11	128	136	27	12	7316183454305	<b>51</b>
Handtag 735	krom	345431-11	128	136	27	12	7316183454312	<b>51</b>
Handtag 735	svart	345432-11	128	136	27	12	7316183454329	<b>51</b>
Handtag 735	rostfri look	34544-11	160	168	27	12	7316183454404	<b>63</b>
Handtag 735	krom	345441-11	160	168	27	12	7316183454411	<b>63</b>
Handtag 735	svart	345442-11	160	168	27	12	7316183454428	<b>63</b>
Handtag 735	rostfri look	34545-11	224	232	27	12	7316183454503	<b>96</b>
Handtag 735	krom	345451-11	224	232	27	12	7316183454510	<b>96</b>
Handtag 735	svart	345452-11	224	232	27	12	7316183454527	<b>96</b>
Handtag 735 5-p	rostfri look	34543-15	128	136	12	27	7316185300433	<b>203</b>
Handtag 7860	alu-look	318900-11	96	111	10	29	7316183189009	<b>41</b>
Handtag 7860	svart	318903-11	96	111	10	29	7316183189030	<b>41</b>
Handtag 7861	alu-look	3190-11	128	149	10	28	7316183190005	<b>51</b>
Handtag 7861	svart	3193-11	128	149	10	28	7316183193006	<b>51</b>
Handtag 7861 5-p	alu-look	3190-15	128	149	10	28	7316185300952	<b>198</b>
Handtag 8443	oxid	31952-11	96	110	15	30	7316183195208	<b>49</b>
Handtag 8443	smide	31953-11	96	110	15	30	7316183195303	<b>54</b>
Handtag 8443	tenn	31954-11	96	110	15	30	7316183195406	<b>49</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag A-1	bok	150687-11	87	105	20	29	7316181506877	<b>36</b>
Handtag A-1	bok	1506-11	96	114	20	29	7316181506006	<b>36</b>
Handtag A-1	ek	1502-11	96	114	20	29	7316181502008	<b>36</b>
Handtag A-1	vit	1505-11	96	114	20	29	7316181505009	<b>36</b>
Handtag A-1 5-p	ek	1502-15	96	114	20	29	7316185300358	<b>141</b>
Handtag A-1 5-p	vit	1505-15	96	114	20	29	7316185300365	<b>141</b>
Handtag A-1 5-p	bok	150687-15	87	105	20	29	7316185300112	<b>132</b>
Handtag A-1 5-p	bok	1506-15	96	114	20	29	7316185300372	<b>132</b>
Handtag A-11	bok	1606-11	96	109	22	28	7316181606003	<b>36</b>
Handtag A16	svart	15654-11	128	168	14	20	7316180008471	<b>100</b>
Handtag A16	svart	15684-11	224	264	14	20	7316180008488	<b>118</b>
Handtag A16	ek	15652-11	128	168	16	20	7316181565201	<b>100</b>
Handtag A16	valnöt	15653-11	128	168	16	20	7316181565300	<b>113</b>
Handtag A16	ek	15682-11	224	264	14	20	7316181568202	<b>123</b>
Handtag A16	valnöt	15683-11	224	264	14	20	7316181568301	<b>148</b>
Handtag A-2	bok	1556-11	96	112	16	36	7316181556001	<b>36</b>
Handtag A-2	bok	1560-11	128	144	16	36	7316181560008	<b>51</b>
Handtag A-31	ek	1722-11	128	152	22	30	7316181722000	<b>56</b>
Handtag A-5	ek	1822-11	96	122	12	29	7316181822007	<b>38</b>
Handtag Aero	ek	1622-11	160	217	4	34	7316181622003	<b>113</b>
Handtag Aero	valnöt	1623-11	160	217	4	34	7316181623000	<b>122</b>
Handtag Aero	svart	1624-11	160	217	4	34	7316181624007	<b>148</b>
Handtag Angel	rostfri look	304285-11	128/160				7316183042854	<b>95</b>
Handtag Angel	matt svart	305286-11	128/160				7316183043004	<b>95</b>
Handtag Arch	rostfri look	343258-11	192	208	14	36	7316183432587	<b>159</b>
Handtag Archive	valnöt	163120-11	64	106	33	19	7316180008396	<b>135</b>
Handtag Archive	svart	163121-11	64	106	33	19	7316180008419	<b>109</b>
Handtag Archive	valnöt	163125-11	192	240	33	19	7316180008402	<b>215</b>
Handtag Archive	svart	163126-11	192	240	33	19	7316180008426	<b>176</b>
Handtag Arild	rostfri look	30356-11	128	135	12	30	7316183035603	<b>66</b>
Handtag Arild	alu-look	30357-11	128	135	12	30	7316183035702	<b>66</b>
Handtag Art	gjutjärn svart	343505-11	96	117	28	30	7316180010375	<b>143</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Base	rostfri look	370155-11	160	172	12	32	7316180008501	<b>122</b>
Handtag Base	antik grå	370156-11	160	172	12	32	7316180008518	<b>127</b>
Handtag Bella	borst. mässing	343286-11	160	171	9,5	30	7316180012812	<b>115</b>
Handtag Bella	mattsvart	343287-11	160	171	9,5	30	7316180012829	<b>93</b>
Handtag Bella	grafit grå	343288-11	160	171	9,5	30	7316180012836	<b>88</b>
Handtag Blues	krom	32511-11	160	195	18	26	7316183251102	<b>63</b>
Handtag Blues	rostfri look	32512-11	160	195	18	26	7316183251201	<b>63</b>
Handtag Boarp	smide	3000-11	96	118	23	25	7316183000007	<b>51</b>
Handtag Bolero	krom	32531-11	128	135	8	28	7316183253106	<b>47</b>
Handtag Bolero	rostfri look	32532-11	128	135	8	28	7316183253205	<b>47</b>
Handtag Bolmen	mp pol.obeh	336901-11	96	106	8	29	7316183369012	<b>131</b>
Handtag Bolmen	mp pol.	336902-11	96	106	8	29	7316183369029	<b>119</b>
Handtag Bolmen	mp obeh	336905-11	96	106	8	29	7316183369050	<b>109</b>
Handtag Bolmen	mp pol.obeh	336903-11	128	138	8	29	7316183369036	<b>131</b>
Handtag Bolmen	mp pol	336904-11	128	138	8	29	7316183369043	<b>131</b>
Handtag Bolmen	mp obeh	336906-11	128	138	8	29	7316183369067	<b>124</b>
Handtag Bolmen	förnicklad	336910-11	96	106	8	29	7316180013246	<b>75</b>
Handtag Bolmen	förnicklad	336911-11	128	138	8	29	7316180013253	<b>80</b>
Handtag Boogie	rostfri look	32542-11	128	145	17	24	7316183254202	<b>41</b>
Handtag Boss	rostfri look	3042-11	128	142	14	36	7316183042007	<b>59</b>
Handtag Boss	rostfri look	30421-11	192	205	14	36	7316183042106	<b>62</b>
Handtag Brohult M	förnicklad/svart	397040-11	96	108	13	32,5	7316180000574	<b>113</b>
Handtag Brohult M	förnicklad/svart	397045-11	128	141	13	32,5	7316180000581	<b>120</b>
Handtag Brohult M	förnicklad/vit	397046-11	128	141	13	32,5	7316180000598	<b>120</b>
Handtag Brohult M	pol.mässing/svart	397047-11	128	141	13	32,5	7316180000604	<b>120</b>
Handtag Brohult M	svart/svart	397049-11	128	141	13	32,5	7316180005906	<b>120</b>
Handtag Bull	zink	303821-11	128	139	33	15	7316183038215	<b>63</b>
Handtag Bull	antik brun	303822-11	128	139	33	15	7316183038222	<b>76</b>
Handtag Bull	zink	303824-11	160	171	33	15	7316183038246	<b>90</b>
Handtag Bull	antik brun	303825-11	160	171	33	15	7316183038253	<b>113</b>
Handtag Button	antik tenn	370220-11	160	175	17	25	7316180008105	<b>148</b>
Handtag Button	antik mässing	370221-11	160	175	17	25	7316180008112	<b>148</b>
Handtag Button	svart	370222-11	160	175	17	25	7316180008129	<b>148</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Car	rostfri look	46002-11	160	181	17/13	27	7316184600206	<b>141</b>
Handtag Car	rostfri look	46006-11	256	277	16/12	27	7316184600602	<b>165</b>
Handtag Care Time	rf-look	303412C-11	128	136	16	26	7316180018012	<b>65</b>
Handtag Care Time	matt svart	303413C-11	128	136	16	26	7316180018029	<b>65</b>
Handtag Care 0143	matt svart	305923C-11	128	137	9	28	7316180018043	<b>75</b>
Handtag Care 0143	rf-look	30592C-11	128	137	9	28	7316180018036	<b>75</b>
Handtag Care 1353	rf-look	330611C-11	128	142	7	34	7316180018098	<b>80</b>
Handtag Care 1353	matt svart	330632C-11	128	142	7	34	7316180018104	<b>80</b>
Handtag Care 1353	rf-look	330699C-11	96	110	7	34	7316180018074	<b>60</b>
Handtag Care 1353	matt svart	331196C-11	96	110	7	34	7316180018081	<b>60</b>
Handtag Cha-Cha	rostfri look	31371-11	160/192	206	13	26	7316183137109	<b>63</b>
Handtag Classic	antik koppar	304130-11	160	186	18	38	7316183041307	<b>184</b>
Handtag Classic	rf-look	304131-11	160	186	18	38	7316183041314	<b>184</b>
Handtag Classic	antik grå	304132-11	160	186	18	38	7316183041321	<b>184</b>
Handtag Cliff Round	rostfri look	303841-11	20	40	41	18	7316183038413	<b>51</b>
Handtag Cliff Round	rostfri look	303843-11	192	200	41	18	7316183038437	<b>113</b>
Handtag Cliff Round	rostfri look	303845-11	320	350	41	18	7316183038451	<b>158</b>
Handtag Common	antik koppar	304120-11	160	170	19	30	7316183041208	<b>140</b>
Handtag Common	rf-look	304121-11	160	170	19	30	7316183041215	<b>131</b>
Handtag Compact	rostfri look	370200-11	160	172	8	36	7316180008716	<b>153</b>
Handtag Compact	antracit	370201-11	160	172	8	36	7316180008723	<b>153</b>
Handtag Compact	svart	370202-11	160	172	8	36	7316180008730	<b>153</b>
Handtag Curve	matt vit	343471-11	32	45	36	17	7316183434710	<b>47</b>
Handtag Curve	matt svart	343472-11	32	45	36	17	7316183434727	<b>47</b>
Handtag Curve	rostfri look	343473-11	32	45	36	17	7316183434734	<b>44</b>
Handtag Curve	matt vit	343477-11	128	200	36	17	7316183434772	<b>70</b>
Handtag Curve	matt svart	343478-11	128	200	36	17	7316183434789	<b>70</b>
Handtag Curve	rostfri look	343479-11	128	200	36	17	7316183434796	<b>70</b>
Handtag Cutt	rostfri look	304275-11	128	200	17,5	23	7316183042755	<b>150</b>
Handtag Cutt	rostfri look	304276-11	320	400	18	23	7316183042762	<b>260</b>
Handtag Cutt	svart	304274-11	96/128	200	23	17,5	7316180003827	<b>149</b>
Handtag Cutt	svart	304277-11	192/320	400	23	17,5	7316180003834	<b>249</b>
Handtag Doppia	rostfri look	304175-11	168/296	168	8	30	7316183041758	<b>80</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Doppia	rostfri look	304176-11	256/288	296	8	30	7316183041765	<b>138</b>
Handtag Edge Bow	krom	460175-11	160	200	18	40	7316184601753	<b>183</b>
Handtag Edge Bow	rostfri look	460176-11	160	200	18	40	7316184601760	<b>119</b>
Handtag Edge Bow	krom	460177-11	160	350	18	40	7316184601777	<b>305</b>
Handtag Edge Bow	rostfri look	460178-11	160	350	18	40	7316184601784	<b>192</b>
Handtag Envelope- 160	borstad mässing	352030-11	160	199	24	25	7316180021074	<b>423</b>
Handtag Envelope- 160	borstad svart	352031-11	160	199	24	25	7316180021081	<b>423</b>
Handtag Este	rf-look	343280-11	160	171	9,5	30	7316180012775	<b>110</b>
Handtag Este	borst. mässing	343281-11	160	171	9,5	30	7316180012782	<b>103</b>
Handtag Este	mattsvart	343282-11	160	171	9,5	30	7316180012799	<b>93</b>
Handtag Este	grafit grå	343283-11	160	171	9,5	30	7316180012805	<b>93</b>
Handtag Fall	rostfri look	370190-11	16	28	20	30	7316180008648	<b>83</b>
Handtag Fall	rostfri look	370191-11	128	140	20	30	7316180008655	<b>135</b>
Handtag Fall	rostfri look	370192-11	224	236	20	30	7316180008686	<b>176</b>
Handtag Fall	borstad mattsvart	370193-11	16	28	20	30	7316180008679	<b>83</b>
Handtag Fall	borstad mattsvart	370194-11	128	140	20	30	7316180008693	<b>135</b>
Handtag Fall	borstad mattsvart	370195-11	224	236	20	30	7316180008709	<b>176</b>
Handtag Firm- 96	mattsvart	343330-11	96	125,8	24,5	29,5	7316180021234	<b>323</b>
Handtag Firm- 160	mattsvart	343331-11	160	189,8	24,5	29,5	7316180021241	<b>373</b>
Handtag Firm- 320	mattsvart	343332-11	320	349,8	24,5	29,5	7316180021258	<b>488</b>
Handtag Floid	antik mässing	345910-11	128	144	16	31	7316180019873	<b>90</b>
Handtag Floid	matt svart	345911-11	128	144	16	31	7316180019897	<b>80</b>
Handtag Floid	antik mässing	345912-11	192	207	16	31	7316180019880	<b>115</b>
Handtag Floid	matt svart	345913-11	192	207	16	31	7316180019903	<b>100</b>
Handtag Frank	mattsvart	345725-11	160	170	13,7	27	7316180016858	<b>68</b>
Handtag Frank	rf-look	345726-11	160	170	13,7	27	7316180016865	<b>73</b>
Handtag Frank	mattb.mässing	345727-11	160	170	13,7	27	7316180017961	<b>83</b>
Handtag Fold	rf-look	304150-11	160	170	18	32	7316183041505	<b>126</b>
Handtag Fold	antik grå	304151-11	160	170	18	32	7316183041512	<b>126</b>
Handtag Fold	antik koppar	304152-11	160	170	18	32	7316183041529	<b>126</b>
Handtag Form	rostfri look	303992-11	160	260	7/14	31	7316183039922	<b>165</b>
Handtag Fringe	borstad mässing	307220-11	160	170	30,4	25,9	7316180012942	<b>153</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Fringe	rf-look	307221-11	160	170	30,4	25,9	7316180012959	<b>153</b>
Handtag Fringe	borst. mattsvart	307222-11	160	170	30,4	25,9	7316180012966	<b>153</b>
Handtag Graf Big	rf-look	370325-11	192	224	14	41	7316180016667	<b>203</b>
Handtag Graf Big	matt mässing	370326-11	192	224	14	41	7316180016674	<b>203</b>
Handtag Graf Big	svart	370327-11	192	224	14	41	7316180016681	<b>203</b>
Handtag Graf Big	rf-look	370330-11	320	352	14	41	7316180016698	<b>240</b>
Handtag Graf Big	matt mässing	370331-11	320	352	14	41	7316180016704	<b>240</b>
Handtag Graf Big	svart	370332-11	320	352	14	41	7316180016711	<b>240</b>
Handtag Graf Big	rf-look	370320-11	1168	1200	14	41	7316180016636	<b>700</b>
Handtag Graf Big	matt mässing	370321-11	1168	1200	14	41	7316180016643	<b>700</b>
Handtag Graf Big	svart	370322-11	1168	1200	14	41	7316180016650	<b>700</b>
Handtag Graf mini	mässing	370230-11	160	182	10	33	7316180008150	<b>153</b>
Handtag Graf mini	mattsvart	370231-11	160	182	10	33	7316180008167	<b>153</b>
Handtag Graf mini	rostfri look	370232-11	160	182	10	33	7316180011211	<b>148</b>
Handtag Graf mini	mässing	370235-11	256	278	10	33	7316180011228	<b>168</b>
Handtag Graf mini	mattsvart	370236-11	256	278	10	33	7316180011235	<b>168</b>
Handtag Graf mini	rostfri look	370237-11	256	278	10	33	7316180011242	<b>168</b>
Handtag Graf mini	mässing	370240-11	1178	1200	10	33	7316180011259	<b>548</b>
Handtag Graf mini	mattsvart	370241-11	1178	1200	10	33	7316180011266	<b>548</b>
Handtag Graf mini	rostfri look	370242-11	1178	1200	10	33	7316180011273	<b>548</b>
Handtag Helix	matt svart	309000-11	128	137	12	35	7316180003193	<b>189</b>
Handtag Helix	antik brons	309001-11	128	137	12	35	7316180003209	<b>225</b>
Handtag Helix	rf-look	309002-11	128	137	12	35	7316180003216	<b>189</b>
Handtag Helix	mässing	309003-11	128	137	12	35	7316180005784	<b>231</b>
Handtag Helix	mattsvart	309005-11	224	233	10	35	7316180003223	<b>234</b>
Handtag Helix	antik brons	309006-11	224	233	10	35	7316180003230	<b>279</b>
Handtag Helix	rf-look	309007-11	224	233	10	35	7316180003247	<b>234</b>
Handtag Helix	mässing	309008-11	224	233	10	35	7316180005791	<b>284</b>
Handtag Helix	rf-look	308502-11	160	170	12	35	7316180012997	<b>178</b>
Handtag Helix	mässing	308503-11	160	170	12	35	7316180013000	<b>228</b>
Handtag Helix	mattsvart	308500-11	160	170	12	35	7316180013017	<b>178</b>
Handtag Helix	antik brons	308501-11	160	170	12	35	7316180013024	<b>228</b>
Handtag Helix	rf-look	308512-11	320	330	12	35	7316180013031	<b>250</b>
Handtag Helix	mässing	308513-11	320	330	12	35	7316180013048	<b>305</b>
Handtag Helix	mattsvart	308510-11	320	330	12	35	7316180013055	<b>250</b>
Handtag Helix	antik brons	308511-11	320	330	12	35	7316180013062	<b>305</b>
Handtag Helix	matt svart	308580-11	608	617	12	35	7316180018821	<b>450</b>
Handtag Helix	antik brons	308581-11	608	617	12	35	7316180018838	<b>500</b>
Handtag Helix	mässing	308582-11	608	617	12	35	7316180018845	<b>500</b>
Handtag Helix	rf-look	308583-11	608	617	12	35	7316180018852	<b>450</b>



Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Helix/bricka	matt svart	309080-11	128	170	10	37	7316180004404	257
Handtag Helix/bricka	antik brons	309081-11	128	170	10	37	7316180004411	308
Handtag Helix/bricka	rf-look	309082-11	128	170	10	37	7316180004428	257
Handtag Helix/bricka	mässing	309083-11	128	170	10	37	7316180005814	284
Handtag Helix/bricka	matt svart	309085-11	224	266	10	37	7316180004435	340
Handtag Helix/bricka	antik brons	309086-11	224	266	10	37	7316180004442	401
Handtag Helix/bricka	rf-look	309087-11	224	266	10	37	7316180004459	340
Handtag Helix/bricka	mässing	309088-11	224	266	10	37	7316180005821	420
Handtag Helix/bricka	rf-look	308542-11	160	235	15	37	7316180013109	248
Handtag Helix/bricka	mässing	308543-11	160	235	15	37	7316180013093	313
Handtag Helix/bricka	mattsvart	308540-11	160	235	15	37	7316180013086	248
Handtag Helix/bricka	antik brons	308541-11	160	235	15	37	7316180013079	313
Handtag Helix/bricka	rf-look	308552-11	320	363	15	37	7316180013116	355
Handtag Helix/bricka	mässing	308553-11	320	363	15	37	7316180013123	435
Handtag Helix/bricka	mattsvart	308550-11	320	363	15	37	7316180013130	355
Handtag Helix/bricka	antik brons	308551-11	320	363	15	37	7316180013147	435
Handtag Helix/bricka	mattsvart	308590-11	608	683	15	37	7316180018869	600
Handtag Helix/bricka	antikbrons	308591-11	608	683	15	37	7316180018876	700
Handtag Helix/bricka	mässing	308592-11	608	683	15	37	7316180018883	700
Handtag Helix/bricka	rf-look	308593-11	608	683	15	37	7316180018890	600
Handtag Helix Stripe	mattsvart	309270-11	128	138	10	34	7316180018708	180
Handtag Helix Stripe	antikbrons	309271-11	128	138	10	34	7316180018715	213
Handtag Helix Stripe	mässing	309272-11	128	138	10	34	7316180018722	213
Handtag Helix Stripe	rf-look	309273-11	128	138	10	34	7316180018739	180
Handtag Helix Stripe	mattsvart	309280-11	160	170	10	34	7316180018746	190
Handtag Helix Stripe	antikbrons	309281-11	160	170	10	34	7316180018753	220
Handtag Helix Stripe	mässing	309282-11	160	170	10	34	7316180018760	220
Handtag Helix Stripe	rf-look	309283-11	160	170	10	34	7316180018777	190
Handtag Helix Stripe	mattsvart	309290-11	224	234	10	34	7316180018784	220
Handtag Helix Stripe	antikbrons	309291-11	224	234	10	34	7316180018791	245
Handtag Helix Stripe	mässing	309292-11	224	234	10	34	7316180018807	245
Handtag Helix Stripe	rf-look	309293-11	224	234	10	34	7316180018814	220
Handtag Helix Stripe/bricka	matt svart	309274-11	128	170	15	37	7316180020701	238
Handtag Helix Stripe/bricka	antik brons	309275-11	128	170	15	37	7316180020718	275
Handtag Helix Stripe/bricka	mässing	309276-11	128	170	15	37	7316180020725	275
Handtag Helix Stripe/bricka	rf-look	309277-11	128	170	15	37	7316180020732	238
Handtag Helix Stripe/bricka	matt svart	309284-11	160	202	15	37	7316180020756	250
Handtag Helix Stripe/bricka	antik brons	309285-11	160	202	15	37	7316180020763	300
Handtag Helix Stripe/bricka	mässing	309286-11	160	202	15	37	7316180020770	300
Handtag Helix Stripe/bricka	rf-look	309287-11	160	202	15	37	7316180020787	250
Handtag Helix Stripe/bricka	matt svart	309294-11	224	266	15	37	7316180020794	300
Handtag Helix Stripe/bricka	antik brons	309295-11	224	266	15	37	7316180020800	350

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Helix Stripe/bricka	mässing	309296-11	224	266	15	37	7316180020817	<b>350</b>
Handtag Helix Stripe/bricka	rf-look	309297-11	224	266	15	37	7316180020824	<b>300</b>
Handtag Hexa- 160	mattsvart	352005-11	160	169	11	33	7316180020930	<b>398</b>
Handtag Hexa- 160	rf-look	352006-11	160	169	11	33	7316180020947	<b>398</b>
Handtag Ink	gjutjärn svart	343515-11	32	64	32	30	7316180013154	<b>165</b>
Handtag Karstorp	rostfri look	30390-11	128	143	7,5	34	7316183039007	<b>146</b>
Handtag Karstorp	krom	30391-11	128	143	7,5	34	7316183039106	<b>131</b>
Handtag Karstorp	rostfri look	30394-11	256	271	7,5	34	7316183039403	<b>196</b>
Handtag Karstorp	krom	30395-11	256	271	7,5	34	7316183039502	<b>186</b>
Handtag Karstorp	rostfri look	30398-11	448	463	7,5	34	7316183039809	<b>294</b>
Handtag Karstorp	krom	30399-11	448	463	7,5	34	7316183039908	<b>305</b>
Handtag Kentucky	antik svart	304325-11	160	180	25	25	7316180004022	<b>114</b>
Handtag Kentucky	antik tenn	304326-11	160	180	25	25	7316180003711	<b>101</b>
Handtag Key	rostfri look	304023-11	160	190	5/19	35	7316183040232	<b>146</b>
Handtag Key	rostfri look	304026-11	320	350	5/19	35	7316183040263	<b>199</b>
Handtag Knistad	krom	398007-11	96	137	20	27	7316183980071	<b>61</b>
Handtag Knistad	tenn	398008-11	96	137	20	27	7316183980088	<b>61</b>
Handtag Laia mini	rostfri look	34311-11	160/192	221	7	28	7316183431108	<b>93</b>
Handtag Laia mini	vit	34315-11	160/192	221	7	28	7316183431504	<b>93</b>
Handtag Laia mini	matt svart	34316-11	160/192	221	7	28	7316183431603	<b>93</b>
Handtag Lecco	antik	345790-11	160	168	30	16,5	7316180017305	<b>168</b>
Handtag Lecco	antik	345794-11	320	328	30	16,5	7316180017329	<b>293</b>
Handtag Lecco	mattsvart	345791-11	160	168	30	16,5	7316180017312	<b>143</b>
Handtag Lecco	mattsvart	345795-11	320	328	30	16,5	7316180017336	<b>253</b>
Handtag Lines	rf-look	343220-11	160	170	17	30	7316180017213	<b>135</b>
Handtag Lines	mattb. mässing	343221-11	160	170	17	30	7316180017220	<b>153</b>
Handtag Lines	mattb. antracit	343222-11	160	170	17	30	7316180017237	<b>153</b>
Handtag Lines	mattsvart	343223-11	160	170	17	30	7316180017244	<b>125</b>
Handtag Light	rostfri look	304180-11	160	176	16	25	7316183041802	<b>89</b>
Handtag Lip	mässing	343456-11	80	120	39	12	7316180005913	<b>158</b>
Handtag Lip	krom	343457-11	80	120	39	12	7316180007498	<b>153</b>
Handtag Lip	svart	343458-11	80	120	39	12	7316180005937	<b>158</b>
Handtag Lip	mässing pol.obeh	343455-11	80	120	39	12	7316180018265	<b>158</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Lip	pol.mässing	343451-11	40	40	38	12	7316183434512	80
Handtag Lip	pol.koppar	343452-11	40	40	38	12	7316181000726	80
Handtag Lip	krom	343453-11	40	40	38	12	7316181000733	80
Handtag Lip	svart	343454-11	40	40	38	12	7316180002356	80
Handtag Lip	mässing pol.obeh	343450-11	40	40	38	12	7316180018258	80
Handtag Loop	svart/mässing	333161-11		160	25		7316183331613	146
Handtag Loop	svart/koppar	333162-11		160	25		7316183331620	146
Handtag Loop	svart/pol.krom	333163-11		160	25		7316183331637	146
Handtag Loop	svart/svart	333164-11		160	25		7316180000994	146
Handtag Loop	brun/mässing	333171-11		160	25		7316183331712	146
Handtag Loop	brun/koppar	333172-11		160	25		7316183331729	146
Handtag Loop	brun/pol.krom	333173-11		160	25		7316183331736	146
Handtag Loop	brun/svart	333174-11		160	25		7316180001007	146
Handtag Loop	natur/mässing	333181-11		160	25		7316183331811	146
Handtag Loop	natur/koppar	333182-11		160	25		7316183331828	146
Handtag Loop	natur/pol.krom	333183-11		160	25		7316183331835	146
Handtag Loop	natur/svart	333184-11		160	25		7316180001014	146
Handtag Loop Round	svart/mässing	333261-11		160	25		7316180000369	155
Handtag Loop Round	svart/koppar	333262-11		160	25		7316180000376	155
Handtag Loop Round	svart/pol.krom	333263-11		160	25		7316180000383	155
Handtag Loop Round	svart/svart	333264-11		160	25		7316180002370	155
Handtag Loop Round	brun/mässing	333271-11		160	25		7316180000390	155
Handtag Loop Round	brun/koppar	333272-11		160	25		7316180000406	155
Handtag Loop Round	brun/pol.krom	333273-11		160	25		7316180000413	155
Handtag Loop Round	brun/svart	333274-11		160	25		7316180002448	155
Handtag Loop Round	natur/mässing	333281-11		160	25		7316180000420	155
Handtag Loop Round	natur/koppar	333282-11		160	25		7316180000437	155
Handtag Loop Round	natur/pol.krom	333283-11		160	25		7316180000444	155
Handtag Loop Round	natur/svart	333284-11		160	25		7316180002462	155
Handtag Lounge	krom/svart	370100-11	160	174	35		7316180000543	391
Handtag Lounge	mässing/brun	370103-11	160	174	35		7316180000550	428
Handtag Lounge	rostfritt/svart	370106-11	160	174	35		7316180000567	428
Handtag Lounge	svart/svart	370109-11	160	174	35		7316180003599	401
Handtag Lounge	krom	370120-11	160	174	35		7316180001618	164
Handtag Lounge	mässing pol.	370121-11	160	174	35		7316180001632	257
Handtag Lounge	rostfritt	370122-11	160	174	35		7316180001656	146
Handtag Lounge	svart	370123-11	160	174	35		7316180003605	178
Handtag Lounge	borst.mässing	370124-11	160	174	35		7316180012973	245
Handtag Luck	borst. mässing	307210-11	32	40,5	8	40	7316180012850	53
Handtag Luck	rf-look	307211-11	32	40,5	8	40	7316180012867	53

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Luck	svart	307212-11	32	40,5	8	40	7316180012898	<b>53</b>
Handtag Luck	borst. mässing	307215-11	160	160	8	40	7316180012904	<b>168</b>
Handtag Luck	rf-look	307216-11	160	160	8	40	7316180012911	<b>168</b>
Handtag Luck	svart	307217-11	160	160	8	40	7316180012928	<b>168</b>
Handtag Lya	rostfri look	303871-11	160	200	9	30	7316183038710	<b>171</b>
Handtag Lya	krom	303872-11	160	200	9	30	7316183038727	<b>148</b>
Handtag Lya	svart	303873-11	160	200	9	30	7316183038734	<b>165</b>
Handtag Lya	rostfri look	303874-11	320	360	9	30	7316183038741	<b>253</b>
Handtag Lya	krom	303875-11	320	360	9	30	7316183038758	<b>165</b>
Handtag Lya	svart	303876-11	320	360	9	30	7316183038765	<b>240</b>
Handtag Lya	rostfri look	303877-11	448	488	9	30	7316183038772	<b>298</b>
Handtag Läckö	oxid	30342-11	96	120	23	26	7316183034200	<b>51</b>
Handtag Läckö	tenn	30343-11	96	120	23	26	7316183034309	<b>51</b>
Handtag Malen	tenn	30378-11	128	150	10	32	7316183037805	<b>70</b>
Handtag Malen	rostfri look	30379-11	128	148	15	25	7316183037904	<b>67</b>
Handtag Malen	tenn	303775-11	160	182	15	28	7316183037751	<b>83</b>
Handtag Malen	rostfri look	303776-11	160	182	15	28	7316183037768	<b>80</b>
Handtag Malen	rostfri look	30381-11	224	240	14	31	7316183038109	<b>90</b>
Handtag Malen 5-p	rostfri look	30379-15	128	148	15	25	7316185300792	<b>264</b>
Handtag Manor	mässing antik	351000-11	128	182	14	39	7316180018272	<b>245</b>
Handtag Manor	matt svart	351001-11	128	182	14	39	7316180018289	<b>245</b>
Handtag Manor	mässing antik	351005-11	192	246	14	39	7316180018296	<b>313</b>
Handtag Manor	matt svart	351006-11	192	246	14	39	7316180018302	<b>313</b>
Handtag Manor / bricka	mässing antik	351010-11	128	190	14	39	7316180018319	<b>313</b>
Handtag Manor / bricka	matt svart	351011-11	128	190	14	39	7316180018326	<b>313</b>
Handtag Manor / bricka	mässing antik	351015-11	192	254	14	39	7316180018333	<b>400</b>
Handtag Manor / bricka	matt svart	351016-11	192	254	14	39	7316180018340	<b>400</b>
Handtag Manta	ek	16301-11	160	240	24	26	7316181630107	<b>148</b>
Handtag Manta	valnöt	16302-11	160	240	24	26	7316181630206	<b>179</b>
Handtag Manta	svart	16300-11	160	240	24	26	7316180013376	<b>190</b>
Handtag Manta mini	ek	16303-11	32	80	24	26	7316181630305	<b>79</b>
Handtag Manta mini	valnöt	16304-11	32	80	24	26	7316181630404	<b>108</b>
Handtag Mora	rostfri look	32401-11	96	117		21	7316183240106	<b>41</b>
Handtag Mora	tennoxid	32403-11	96	117		21	7316183240304	<b>41</b>
Handtag Mölle	rostfri look	30353-11	128	145	12	25	7316183035306	<b>46</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Nick	rf-look	304290-11	32	50	13	24	7316180003841	<b>66</b>
Handtag Nick	borst mässing	304291-11	32	50	13	24	7316180003865	<b>69</b>
Handtag Nick	rf-look	304294-11	160	178	13	24	7316180003858	<b>152</b>
Handtag Nick	borst mässing	304295-11	160	178	13	24	7316180003872	<b>158</b>
Handtag Norma 1021	rostfritt stål	339571-11	128	142	14	35	7316183395714	<b>100</b>
Handtag Norma 1021	rostfritt stål	339572-11	192	206	14	35	7316183395721	<b>106</b>
Handtag Norma 12	rostfritt stål	34401-11	128	140	12	32	7316183440100	<b>113</b>
Handtag Norma 12	rostfritt stål	34402-11	192	204	12	32	7316183440209	<b>126</b>
Handtag Norma 12	rf/svart läder	343901-11	128	140	12	32	7316183439012	<b>418</b>
Handtag Norma 12	rf/svart läder	343902-11	192	204	12	32	7316183439019	<b>453</b>
Handtag Norma 12	rf/brunt läder	343905-11	128	140	12	32	7316183439050	<b>418</b>
Handtag Norma 12	rf/brunt läder	343906-11	192	204	12	32	7316183439067	<b>453</b>
Handtag Pagoda	gjutjärn svart	343520-11	32	44	13	33	7316180013161	<b>115</b>
Handtag Pagoda	gjutjärn svart	343525-11	160	173	13	38	7316180013178	<b>168</b>
Handtag Penn	gjutjärn svart	343530-11	128	183	11	32	7316180013185	<b>168</b>
Handtag Pitch	matt svart	309065-11	128	193	10	35	7316180003292	<b>258</b>
Handtag Pitch	matt svart	309070-11	192	257	10	35	7316180003308	<b>286</b>
Handtag Pitch/bricka	matt svart	309115-11	128	193	10	35	7316180005838	<b>340</b>
Handtag Pitch/bricka	matt svart	309120-11	192	257	10	35	7316180005845	<b>386</b>
Handtag Portland	svart	308600-11	192	242	20	33	7316180013383	<b>178</b>
Handtag Portland	antik brons	308601-11	192	242	20	33	7316180013390	<b>218</b>
Handtag Pronto	borst mässing	304312-11	160	166	10	30	7316180003674	<b>123</b>
Handtag Pronto	svart	304313-11	160	166	10	30	7316180003681	<b>106</b>
Handtag Pronto	rostfri look	304310-11	160	166	10	30	7316181002201	<b>99</b>
Handtag Pronto	antik koppar	304311-11	160	166	10	30	7316181002300	<b>99</b>
Handtag Provence	gjutjärn svart	343500-11	160	179	13	38	7316180010351	<b>181</b>
Handtag Pura	mässing	343320-11	160	168	8	28	7316180019934	<b>118</b>
Handtag Pura	krom	343321-11	160	168	8	28	7316180019941	<b>100</b>
Handtag Påarp	rostfri look	303881-11	160	173	16	30	7316183038819	<b>155</b>
Handtag Påarp	krom	303882-11	160	173	16	30	7316183038826	<b>125</b>
Handtag Påarp	svart	303883-11	160	173	16	30	7316183038833	<b>171</b>
Handtag Påarp	rostfri look	303884-11	320	334	16	30	7316183038840	<b>223</b>
Handtag Påarp	krom	303885-11	320	334	16	30	7316183038857	<b>179</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Påarp	svart	303886-11	320	334	16	30	7316183038864	<b>213</b>
Handtag Rattan- 160	borstad mässing	352010-11	160	168	14	31	7316180020954	<b>398</b>
Handtag Rattan- 160	mattsvart	352011-11	160	168	14	31	7316180020985	<b>398</b>
Handtag Rattan- 160	rf-look	352012-11	160	168	14	31	7316180020992	<b>398</b>
Handtag Redo	antik tenn	343247-11	128	137	15	32	7316180003803	<b>126</b>
Handtag Redo	antik tenn	343248-11	192	201	15	32	7316180003810	<b>138</b>
Handtag Redo	rostfri look	343245-11	128	137	15	32	7316183432457	<b>102</b>
Handtag Redo	rostfri look	343246-11	192	201	15	32	7316183432464	<b>146</b>
Handtag Retro	mattsvart	345750-11	128	149	19	30	7316180017343	<b>55</b>
Handtag Retro	mattsvart	345755-11	160	180	19	30	7316180017367	<b>60</b>
Handtag Retro	mässing	345751-11	128	149	19	30	7316180017350	<b>70</b>
Handtag Retro	mässing	345756-11	160	180	19	30	7316180017374	<b>78</b>
Handtag Rio	antik tenn	460101-11	256	292	16	30	7316180003629	<b>225</b>
Handtag Rio	svart	460102-11	256	292	16	30	7316180003636	<b>202</b>
Handtag Rio	rf-look	460103-11	256	292	16	30	7316180003643	<b>234</b>
Handtag Rio	krom	460165-11	128	164	16	30	7316184601654	<b>125</b>
Handtag Rio	rostfri look	460166-11	128	164	16	30	7316184601661	<b>131</b>
Handtag Rio	antik grå	460167-11	128	164	16	30	7316184601678	<b>165</b>
Handtag Rio	antik brun	460168-11	128	164	16	30	7316184601685	<b>186</b>
Handtag Rio	matt svart	460164-11	128	164	16	30	7316184601647	<b>128</b>
Handtag Rock	rostfri look	304181-11	160	168	20	32	7316183041819	<b>99</b>
Handtag Roma	rostfri look	343251-11	160	175	14	30	7316183432518	<b>138</b>
Handtag Roma	rostfri look	343252-11	192	207	14	30	7316183432525	<b>159</b>
Handtag Royal	mässing pol.	336210-11	96	114	20	32	7316181000740	<b>181</b>
Handtag Royal	förnicklad	336211-11	96	114	20	32	7316181000757	<b>181</b>
Handtag Royal	mattsvart	336212-11	96	114	20	32	7316180007993	<b>151</b>
Handtag Royal	mässing pol.	336215-11	128	146	20	32	7316181000764	<b>216</b>
Handtag Royal	förnicklad	336216-11	128	146	20	32	7316181000771	<b>216</b>
Handtag Royal	mattsvart	336217-11	128	146	20	32	7316180008006	<b>192</b>
Handtag Royal Deluxe	mp/brun	336230-11	128	146	20	32	7316180000208	<b>514</b>
Handtag Royal Deluxe	mp/svart	336231-11	128	146	20	32	7316180000222	<b>514</b>
Handtag Royal Deluxe	förnicklad/brun	336235-11	128	146	20	32	7316180000246	<b>530</b>
Handtag Royal Deluxe	förnicklad/svart	336236-11	128	146	20	32	7316180000260	<b>530</b>
Handtag Salsa	rostfri look	31352-11	128	157	10	22	7316183135204	<b>36</b>
Handtag Salsa	rostfri look	31362-11	192	221	10	22	7316183136201	<b>57</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Saluto	svart	308610-11	96	134	20	24	7316180013420	<b>168</b>
Handtag Saluto	pol.nickel	308611-11	96	134	20	24	7316180013437	<b>168</b>
Handtag Saluto	svart	308615-11	160	198	20	24	7316180013505	<b>193</b>
Handtag Saluto	pol.nickel	308616-11	160	198	20	24	7316180013512	<b>193</b>
Handtag Samba	krom	31321-11	128	158	12	30	7316183132104	<b>47</b>
Handtag Samba	rostfri look	31322-11	128	158	12	30	7316183132203	<b>47</b>
Handtag Samba	tenn	31324-11	128	158	12	30	7316183132401	<b>47</b>
Handtag Seam- 160	mattsvart	352035-11	160	169	15	29	7316180021098	<b>248</b>
Handtag Seam- 160	rf-look	352036-11	160	169	15	29	7316180021111	<b>248</b>
Handtag Seam- 320	mattsvart	352040-11	320	329	15	29	7316180021128	<b>438</b>
Handtag Seam- 320	rf-look	352041-11	320	329	15	29	7316180021135	<b>423</b>
Handtag Sense mini	rf-look	343265-11	160	167	17	30	7316180003780	<b>92</b>
Handtag Sense mini	rf-look	343266-11	256	263	17	30	7316180003797	<b>126</b>
Handtag Sense mini	brons	343271-11	160	167	17	30	7316180018456	<b>118</b>
Handtag Sense mini	brons	343272-11	256	263	17	30	7316180018463	<b>152</b>
Handtag Sense mini	svart	343269-11	160	167	17	30	7316180003742	<b>94</b>
Handtag Sense mini	svart	343270-11	256	263	17	30	7316180003759	<b>149</b>
Handtag Skanör	rostfri look	30366-11	96	112	7	20	7316183036600	<b>33</b>
Handtag Skanör	rostfri look	30367-11	128	157	10	27	7316183036709	<b>39</b>
Handtag Slim 4025	aluminium	30517-11		40	40	18	7316183051702	<b>51</b>
Handtag Slim 4025	krom	305171-11		40	40	18	7316183051719	<b>51</b>
Handtag Slim 4025	rostfri look	305172-11		40	40	18	7316183051726	<b>51</b>
Handtag Slim 4025	svart	305175-11		40	40	18	7316183051757	<b>51</b>
Handtag Slim 4025	vit	305174-11		40	40	18	7316183051740	<b>51</b>
Handtag Slim 4025	aluminium	30518-11		136	40	18	7316183051801	<b>67</b>
Handtag Slim 4025	krom	305181-11		136	40	18	7316183051818	<b>67</b>
Handtag Slim 4025	rostfri look	305182-11		136	40	18	7316183051825	<b>67</b>
Handtag Slim 4025	svart	305176-11		136	40	18	7316183051764	<b>67</b>
Handtag Slim 4025	vit	305184-11		136	40	18	7316183051849	<b>67</b>
Handtag Slim 4025	aluminium	30519-11		232	40	18	7316183051900	<b>100</b>
Handtag Slim 4025	krom	305191-11		232	40	18	7316183051917	<b>100</b>
Handtag Slim 4025	rostfri look	305192-11		232	40	18	7316183051924	<b>100</b>
Handtag Slim 4025	svart	305196-11		232	40	18	7316183051962	<b>100</b>
Handtag Slim 4025	vit	305194-11		232	40	18	7316183051948	<b>92</b>
Handtag Smögen	rostfri look	30362-11	96	135	16	23	7316183036204	<b>49</b>
Handtag Smögen	rostfri look	30364-11	128	180	22	23	7316183036402	<b>62</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Soft	mässing	306004-11	128	135	8	28	7316180012584	<b>63</b>
Handtag Soft	mässing	306008-11	192	199	8	28	7316180012591	<b>88</b>
Handtag Soft	koppar pol.	306001-11	128	135	8	28	7316181000788	<b>80</b>
Handtag Soft	matt svart	306002-11	128	135	8	28	7316181000795	<b>62</b>
Handtag Soft	rf-look	306003-11	128	135	8	28	7316181001600	<b>74</b>
Handtag Soft	koppar pol.	306005-11	192	199	8	28	7316181000801	<b>111</b>
Handtag Soft	matt svart	306006-11	192	199	8	28	7316181000818	<b>92</b>
Handtag Soft	rf-look	306007-11	192	199	8	28	7316181001709	<b>101</b>
Handtag Solaris	tennoxid	30662N-11	128	154	14	34	7316183066201	<b>73</b>
Handtag SS-A	rostfritt stål	339625-11	96	106	10	35	7316183396254	<b>64</b>
Handtag SS-A	rostfritt stål	339626-11	128	138	10	35	7316183396261	<b>74</b>
Handtag SS-A	rostfritt stål	339627-11	192	202	10	35	7316183396278	<b>89</b>
Handtag SS-A	rostfritt stål	339630-11	480	490	10	35	7316183396308	<b>196</b>
Handtag SS-A	rf/brun läder	339640-11	128	138	10	35	7316180001663	<b>356</b>
Handtag SS-A	rf/natur läder	339641-11	128	138	10	35	7316180001670	<b>356</b>
Handtag SS-A	rf/svart läder	339642-11	128	138	10	35	7316180001687	<b>356</b>
Handtag SS-A	rf/brun läder	339645-11	192	202	10	35	7316180001694	<b>386</b>
Handtag SS-A	rf/natur läder	339646-11	192	202	10	35	7316180001700	<b>386</b>
Handtag SS-A	rf/svart läder	339647-11	192	202	10	35	7316180001717	<b>386</b>
Handtag SS-A lädersvept	rostfritt/svart	339710-11	128	138	10	35	7316180007917	<b>218</b>
Handtag SS-A lädersvept	rostfritt/brunt	339711-11	128	138	10	35	7316180007894	<b>218</b>
Handtag SS-A lädersvept	rostfritt/natur	339712-11	128	138	10	35	7316180007870	<b>218</b>
Handtag SS-A lädersvept	rostfritt/svart	339715-11	192	202	10	35	7316180007979	<b>269</b>
Handtag SS-A lädersvept	rostfritt/brunt	339716-11	192	202	10	35	7316180007955	<b>269</b>
Handtag SS-A lädersvept	rostfritt/natur	339717-11	192	202	10	35	7316180007931	<b>269</b>
Handtag SS-B	rostfritt stål	339612-11	128	156	10	35	7316183396124	<b>63</b>
Handtag SS-B	rostfritt stål	339614-11	192	221	10	35	7316183396148	<b>76</b>
Handtag SS-C	rostfritt stål	339631-11	96	160	12	34	7316183396315	<b>98</b>
Handtag SS-C	rostfritt stål	339632-11	128	192	12	34	7316183396322	<b>101</b>
Handtag SS-C	rostfritt stål	339634-11	192	256	12	34	7316183396346	<b>122</b>
Handtag SS-C	rostfritt stål	339635-11	224	288	12	34	7316183396353	<b>136</b>
Handtag SS-CH	rostfritt stål	339731-11	96	136	12	34	7316183397312	<b>98</b>
Handtag SS-CH	rostfritt stål	339732-11	128	168	12	34	7316183397329	<b>101</b>
Handtag SS-CH	rostfritt stål	339734-11	192	232	12	34	7316183397343	<b>122</b>
Handtag Stil 555	krom	39709-11	87	112	11	23	7316183970904	<b>51</b>
Handtag Stil 555	krom	39710-11	96	127	26	27	7316180011181	<b>48</b>



Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Studio	mattsvart	345705-11	160	170	11,5	30,5	7316180016834	<b>68</b>
Handtag Studio	rf-look	345706-11	160	170	11,5	30,5	7316180016841	<b>73</b>
Handtag Studio	matt.mässing	345707-11	160	170	11,50	30,5	7316180017954	<b>83</b>
Handtag Strikt	rostfri look	30302-11	96	112	15	27	7316183030202	<b>46</b>
Handtag Strikt	alu-look	3030-11	96	112	15	27	7316183030004	<b>46</b>
Handtag Sun	krom	31301-11	128	149	7	32	7316183130100	<b>41</b>
Handtag Sun	rostfri look	31302-11	128	149	7	32	7316183130209	<b>44</b>
Handtag Sun	krom	31303-11	192	216	7	35	7316183130308	<b>58</b>
Handtag Sun	rostfri look	31304-11	192	216	7	35	7316183130407	<b>61</b>
Handtag Square-OceanIX-12	mattsvart	352055-11	128	138	10	32	7316180021159	<b>248</b>
Handtag Time	pol. mässing	303411-11	128	136	16	26,5	7316183034118	<b>53</b>
Handtag Time	rostfri look	303412-11	128	136	16	27	7316183034125	<b>53</b>
Handtag Tofta	rostfri look	30371-11	96	125	13	25	7316183037102	<b>44</b>
Handtag Tofta	rostfri look	30373-11	128	163	13	25	7316183037300	<b>48</b>
Handtag Track	mattsvart	345781-11	160	168	12,5	33	7316180017268	<b>143</b>
Handtag Track	mattsvart	345785-11	320	328	12,5	33	7316180017299	<b>243</b>
Handtag Transit- 160	rf-look	352065-11	160	219	12	24	7316180021197	<b>348</b>
Handtag Transit- 160	mattsvart	352066-11	160	219	12	24	7316180021203	<b>348</b>
Handtag Tuba	svart	163100-11	128	164	28	19	7316180008334	<b>124</b>
Handtag Tuba	svart	163105-11	256	280	28	19	7316180008341	<b>189</b>
Handtag Tuba	valnöt	163101-11	128	164	28	19	7316180008358	<b>151</b>
Handtag Tuba	valnöt	163106-11	256	280	28	19	7316180008365	<b>223</b>
Handtag Tuba	ek	163102-11	128	164	28	19	7316180008372	<b>133</b>
Handtag Tuba	ek	163107-11	256	280	28	19	7316180008389	<b>197</b>
Handtag Vanilla	vit	370160-11	16	50	30	26	7316180008525	<b>122</b>
Handtag Vanilla	vit	370161-11	96	140	30	26	7316180008532	<b>156</b>
Handtag Vann	mattsvart	370260-11		200	19,7	44	7316180012706	<b>118</b>
Handtag Vann	rf-look	370261-11		200	19,7	44	7316180012713	<b>118</b>
Handtag Vann	borst. mässing	370262-11		200	19,7	44	7316180012720	<b>118</b>
Handtag Vann	mattsvart	370265-11		1200	19,7	44	7316180012737	<b>480</b>
Handtag Vann	rf-look	370266-11		1200	19,7	44	7316180012744	<b>480</b>
Handtag Vann	borst. mässing	370267-11		1200	19,7	44	7316180012751	<b>480</b>
Handtag Wow	rostfri look	303761-11	64	96	42	20	7316183037614	<b>144</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Handtag Wow	rostfri look	303762-11	160	192	42	20	7316183037621	<b>209</b>
Handtag VS-A	rostfri look	339891-11	96	106	10	35	7316183398913	<b>41</b>
Handtag VS-A	rostfri look	339892-11	128	138	10	35	7316183398920	<b>45</b>
Handtag VS-A	rostfri look	339893-11	192	202	10	35	7316183398937	<b>60</b>
Handtag VS-A 5-p	rostfri look	339892-15	128	138	10	35	7316185300051	<b>179</b>
Handtag VS-B	rostfri look	339895-11	96	117	10	35	7316183398951	<b>41</b>
Handtag VS-B	rostfri look	339896-11	128	156	10	35	7316183398968	<b>51</b>
Handtag VS-B	rostfri look	339897-11	192	221	10	35	7316183398975	<b>63</b>
Handtag VS-C	rostfri look	339901-11	96	160	12	34	7316183399019	<b>41</b>
Handtag VS-C	rostfri look	339902-11	128	192	12	34	7316183399026	<b>51</b>
Handtag VS-C	rostfri look	339904-11	192	256	12	34	7316183399040	<b>61</b>
Handtag VS-C 5-p	rostfri look	339901-15	96	160	12	34	7316185300013	<b>159</b>
Handtag VS-C 5-p	rostfri look	339902-15	128	192	12	34	7316185300020	<b>198</b>
Handtag Yazz	rostfri look	32510-11	128	141	15	30	7316183251003	<b>53</b>
Inf.htg 512	rostfri look	303771-11		160	50	10	7316183037713	<b>136</b>
Inf.htg Cubic	mattvit	317410-11		160	24	10	7316180012683	<b>93</b>
Inf.htg Cubic	mattsvart	317411-11		160	24	10	7316180012690	<b>93</b>
Inf.htg Hallow	alu-look	317400-11		40	40	16	7316180012645	<b>68</b>
Inf.htg Hallow	mattsvart	317401-11		40	40	16	7316180012652	<b>68</b>
Inf.htg Hallow	alu-look	317405-11		60	60	16	7316180012669	<b>83</b>
Inf.htg Hallow	mattsvart	317406-11		60	60	16	7316180012676	<b>93</b>
Knopp 0613	smide	3640-11		31	31	29	7316183640005	<b>51</b>
Knopp 2023	krom	36935-11		28	28	34	7316183693506	<b>69</b>
Knopp 2078	alu-look	3680-11		28	28	25	7316183680001	<b>47</b>
Knopp 2078	vit	368051-11		28	28	25	7316183680513	<b>47</b>
Knopp 2078	krom	36801-11		28	28	25	7316183680100	<b>47</b>
Knopp 2078	svart	368053-11		28	28	25	7316183680537	<b>47</b>
Knopp 2078	koppar	368056-11		28	28	25	7316183680568	<b>47</b>
Knopp 2078	mässing pol.	368055-11		28	28	25	7316183680551	<b>47</b>
Knopp 2078	rostfri look	368057-11		28	28	25	7316183680575	<b>47</b>
Knopp 2078	matt vit	368041-11		28	28	25	7316180010290	<b>40</b>
Knopp 2082	tennoxid	36832N-11		31	31	26	7316183683200	<b>47</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Knopp 24136	vit/förnicklad	39631-11		30		30	7316183963104	<b>73</b>
Knopp 24136	vit/tenn	39632-11		30		30	7316183963203	<b>73</b>
Knopp 24136	vit/mässing	39633-11		30		30	7316183963302	<b>73</b>
Knopp 24226	tenn	39512-11		15	15	17	7316183951200	<b>44</b>
Knopp 24226	tenn	39513-11		20	20	25	7316183951309	<b>63</b>
Knopp 24226	tenn	39514-11		24	24	30	7316183951408	<b>73</b>
Knopp 24226	tenn	39515-11		27	27	35	7316183951507	<b>90</b>
Knopp 24226	förnicklad	39522-11		15	15	17	7316183952207	<b>44</b>
Knopp 24226	förnicklad	39523-11		20	20	25	7316183952306	<b>63</b>
Knopp 24226	förnicklad	39524-11		24	24	30	7316183952405	<b>73</b>
Knopp 24226	förnicklad	39525-11		27	27	35	7316183952504	<b>90</b>
Knopp 24466	mäss.pol	39641-11		25		28	7316183964101	<b>70</b>
Knopp 24466	mäss.pol	39643-11		35		28	7316183964309	<b>118</b>
Knopp 24466	förnicklad	39651-11		25		28	7316183965108	<b>90</b>
Knopp 24466	förnicklad	3965-11		35		28	7316183965009	<b>93</b>
Knopp 24466	mässing obeh.	39652-11		25		28	7316180018555	<b>70</b>
Knopp 24466	mässing obeh.	39653-11		35		28	7316180018562	<b>120</b>
Knopp 2538	rostfri look	36950-11		35	25	31	7316183695005	<b>80</b>
Knopp 2538	oxid	36952-11		35	25	31	7316183695203	<b>53</b>
Knopp 2538	tennoxid	36953N-11		35	25	31	7316183695302	<b>53</b>
Knopp 2918	oxid	3622-11		36	36	27	7316183622001	<b>51</b>
Knopp 2918	tenn	3624-11		36	36	27	7316183624005	<b>51</b>
Knopp 401	förnicklad	39032-11		40	29	35	7316183903209	<b>57</b>
Knopp 401	mässing	39033-11		40	29	35	7316183903308	<b>103</b>
Knopp 401	pol.koppar	39034-11		40	29	35	7316183903407	<b>103</b>
Knopp 401	matt mässing	39035-11		40	29	35	7316183903506	<b>103</b>
Knopp 401	rostfri look	39037-11		40	29	35	7316183903704	<b>57</b>
Knopp 401	antik svart	39036-11		40	29	35	7316183903605	<b>57</b>
Knopp 401	antik	3903-11		40	29	35	7316183903001	<b>80</b>
Knopp 401	tenn	39031-11		40	29	35	7316183903100	<b>57</b>
Knopp 401 5-p	tenn	39031-15		40	29	35	7316185300310	<b>225</b>
Knopp 409	antik/porslin	3911-11		37	37	28	7316183911006	<b>66</b>
Knopp 409	krom/porslin	39111-11		37	37	28	7316183911105	<b>66</b>
Knopp 409	tenn/porslin	391111-11		37	37	28	7316183911112	<b>66</b>
Knopp 411	antik	39112-11		13	13	13	7316183911204	<b>28</b>
Knopp 411	antik	39113-11		17	17	15	7316183911303	<b>32</b>
Knopp 411	antik	39114-11		24	24	22	7316183911402	<b>45</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Knopp 411	antik	3912-11		32	32	25	7316183912003	<b>80</b>
Knopp 411	antik	3913-11		40	40	37	7316183913000	<b>136</b>
Knopp 411	mässing obeh.	391310-11		13	13	13	7316180008211	<b>26</b>
Knopp 411	mässing obeh.	391311-11		17	17	15	7316180008228	<b>31</b>
Knopp 411	mässing obeh.	391312-11		24	24	22	7316180008235	<b>52</b>
Knopp 411	mässing obeh.	391313-11		32	32	25	7316180008242	<b>94</b>
Knopp 411	mässing obeh.	391314-11		40	40	37	7316180008259	<b>166</b>
Knopp 411	mässing	391153-11		13	13	13	7316180008778	<b>26</b>
Knopp 411	mässing	391152-11		17	17	15	7316180008266	<b>31</b>
Knopp 411	mässing	391141-11		24	24	22	731618911419	<b>61</b>
Knopp 411	mässing	391151-11		32	32	25	7316189311518	<b>106</b>
Knopp 5320 inkl skruv	förnicklad	397911-11		50	25	32	7316183979112	<b>286</b>
Knopp 5320 inkl skruv	svart	397910-11		50	25	32	7316180013260	<b>250</b>
Knopp 580	vit	4500-11		40	40	35	7316184500001	<b>9</b>
Knopp 580 5-p	vit	4500-15		40	40	35	7316185300341	<b>33</b>
Knopp 7638 S	mässing	3654-11		31	31	34	7316183654002	<b>68</b>
Knopp 8131	grön/antik	4892-11		33	33	42	7316184892007	<b>44</b>
Knopp 8322	koppar	36370-11		28	28	33	7316183637005	<b>78</b>
Knopp 8322	krom	36935-11		28	28	33	7316183693506	<b>69</b>
Knopp 8322 1-p	matt svart	363710-11		28	28	33	7316181000900	<b>64</b>
Knopp 8701	tenn	36363-11		27	35	27	7316183636305	<b>79</b>
Knopp 8701	rostfri look	36360-11		27	35	27	7316183636008	<b>79</b>
Knopp 8701	pol.koppar	36361-11		27	35	27	7316180012560	<b>73</b>
Knopp 8701 5-p	rostfri look	36360-15		27	35	27	7316185300334	<b>313</b>
Knopp Autumn	rostfri look	370175-11		28	28	27	7316180008587	<b>73</b>
Knopp Autumn	rostfri look	370176-11		34	34	36	7316180008594	<b>109</b>
Knopp Autumn	svart	370177-11		27	27	28	7316180008600	<b>73</b>
Knopp Autumn	svart	370178-11		34	34	36	7316180008617	<b>109</b>
Knopp Autumn	mässing	370173-11		28	28	27	7316180012935	<b>65</b>
Knopp Bead Straight	marmor/grön	304061-11		28	28	36	7316180003612	<b>289</b>
Knopp Bead Straight	marmor/grå	304060-11		28	28	36	7316180002516	<b>289</b>
Knopp Bell	rostfri look	370170-11		42	42	32	7316180008556	<b>96</b>
Knopp Bell	antik grå	370171-11		42	42	32	7316180008563	<b>99</b>
Knopp Bell	mattsvart	370172-11		42	42	32	7316180008570	<b>99</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Knopp Bowl	ek	2542-11		65	65	20	7316182542003	<b>90</b>
Knopp Bowl	valnöt	2543-11		65	65	20	7316182543000	<b>96</b>
Knopp Bowl	svart	2544-11		65	65	20	7316182544007	<b>146</b>
Knopp Brutus	ek	255655-11		32	32	25	7316180013314	<b>75</b>
Knopp Brutus	svart	255656-11		32	32	25	7316180013321	<b>75</b>
Knopp Brutus	valnöt	255657-11		32	32	25	7316180013567	<b>90</b>
Knopp Circum	svart	255640-11		33	33	28	7316180008273	<b>88</b>
Knopp Circum	svart	255645-11		48	48	40	7316180008280	<b>109</b>
Knopp Circum	ek	255642-11		33	33	28	7316180008310	<b>91</b>
Knopp Circum	ek	255647-11		48	48	40	7316180008785	<b>106</b>
Knopp Circum	valnöt	255641-11		33	33	28	7316180008297	<b>99</b>
Knopp Circum	valnöt	255646-11		48	48	40	7316180008303	<b>122</b>
Knopp Care 401	rf-look	39037C-11		40	29	40	7316180018135	<b>68</b>
Knopp Care 401	matt svart	39038C-11		40	29	40	7316180018142	<b>68</b>
Knopp Classic	antik koppar	304135-11		34	34	28	7316183041352	<b>113</b>
Knopp Classic	rf-look	304136-11		34	34	28	7316183041369	<b>113</b>
Knopp Classic	antik grå	304137-11		34	34	28	7316183041376	<b>113</b>
Knopp Como	rostfri look	343274-11		26	26	18	7316183432747	<b>43</b>
Knopp Como	krom	343275-11		26	26	18	7316183432754	<b>41</b>
Knopp Como	matt svart	343276-11		26	26	18	7316183432761	<b>41</b>
Knopp Como	borst.mässing	343277-11		26	26	18	7316180012843	<b>45</b>
Knopp Como	mässing	343279-11		26	26	18	7316180019927	<b>58</b>
Knopp Como	mässing	343278-11		41	41	18	7316180019910	<b>85</b>
Knopp Como Big	rf-look	343210-11		41	41	25	7316180017176	<b>98</b>
Knopp Como Big	krom	343211-11		41	41	25	7316180017183	<b>98</b>
Knopp Como Big	mattsvart	343212-11		41	41	25	7316180017190	<b>98</b>
Knopp Como Big	borstad mässing	343213-11		41	41	25	7316180017206	<b>98</b>
Knopp Crest	mattsvart	309130-11		26	26	28	7316180009362	<b>101</b>
Knopp Crest	rf-look	309131-11		26	26	28	7316180009379	<b>112</b>
Knopp Crest	mässing	309133-11		26	26	28	7316180009386	<b>119</b>
Knopp Crest	antik broms	309134-11		26	26	28	7316180009393	<b>119</b>
Knopp Crest	mattsvart	309140-11		32	32	28	7316180009409	<b>122</b>
Knopp Crest	rf-look	309141-11		32	32	28	7316180009416	<b>133</b>
Knopp Crest	mässing	309142-11		32	32	28	7316180009423	<b>145</b>
Knopp Crest	antik brons	309143-11		36	36	28	7316180009430	<b>145</b>
Knopp Crystal	glas/krom	430001-11		30	30	42	7316184300014	<b>76</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Knopp Cuba	krom	304140-11		75	18	36	7316183041406	<b>101</b>
Knopp Cuba	rf-look	304141-11		75	18	36	7316183041413	<b>108</b>
Knopp Dalby	pol.koppar	339413-11		25	25	20	7316183394137	<b>80</b>
Knopp Dalby	mp pol.obeh	339415-11		25	25	20	7316183394151	<b>80</b>
Knopp Dalby	mp pol	339416-11		25	25	20	7316183394168	<b>80</b>
Knopp Diamond	glas/krom	430002-11		30	30	42	7316184300205	<b>76</b>
Knopp Duke	svart	370210-11		32	32	26	7316180008075	<b>76</b>
Knopp Duke	antik tenn	370211-11		32	32	26	7316180008082	<b>76</b>
Knopp Duke	antik mässing	370212-11		32	32	26	7316180008099	<b>76</b>
Knopp Envelope- 32	borstad mässing	352025-11		24	49	25	7316180021050	<b>238</b>
Knopp Envelope- 32	borstad svart	352026-11		24	49	25	7316180021067	<b>238</b>
Knopp Flat	mattsvart	309150-11		26	26	24	7316180009287	<b>88</b>
Knopp Flat	rf-look	309151-11		26	26	24	7316180009294	<b>96</b>
Knopp Flat	mässing	309152-11		26	26	24	7316180009300	<b>104</b>
Knopp Flat	antik brons	309153-11		26	26	24	7316180009317	<b>104</b>
Knopp Flat	mattsvart	309160-11		32	32	26	7316180009324	<b>106</b>
Knopp Flat	rf-look	309161-11		32	32	26	7316180009331	<b>117</b>
Knopp Flat	mässing	309162-11		32	32	26	7316180009348	<b>124</b>
Knopp Flat	antik brons	309163-11		32	32	26	7316180009355	<b>124</b>
Knopp Fleur	gjutjärn svart	343510-11	46			30	7316180010399	<b>114</b>
Knopp Floid	antik mässing	345901-11	14			30	7316180019842	<b>65</b>
Knopp Floid	matt svart	345902-11	14			30	7316180019859	<b>55</b>
Knopp Fold	rf-look	304145-11		40	18	32	7316183041451	<b>95</b>
Knopp Fold	antik grå	304146-11		40	18	32	7316183041468	<b>95</b>
Knopp Fold	antik koppar	304147-11		40	18	32	7316183041475	<b>95</b>
Knopp Gate- 18	mattsvart	352020-11		18	22	18	7316180021036	<b>138</b>
Knopp Gate- 18	rf-look	352021-11		18	22	18	7316180021043	<b>138</b>
Knopp Graf	rostfri look	34331-11		17	17	28	7316183433102	<b>44</b>
Knopp Graf	matt svart	343315-11		17	17	28	7316180004312	<b>43</b>
Knopp Graf	mässing	343316-11		17	17	28	7316180002332	<b>69</b>
Knopp Graf Big	rf-look	370300-11		38	38	30	7316180016575	<b>153</b>
Knopp Graf Big	matt mässing	370301-11		38	38	30	7316180016582	<b>153</b>
Knopp Graf Big	svart	370302-11		38	38	30	7316180016599	<b>153</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Knopp Graf Big	rf-look	370305-11		50	50	30	7316180016605	<b>205</b>
Knopp Graf Big	matt mässing	370306-11		50	50	30	7316180016612	<b>205</b>
Knopp Graf Big	svart	370307-11		50	50	30	7316180016629	<b>205</b>
Knopp Graf mini	mässing	370225-11		10	10	33	7316180008136	<b>47</b>
Knopp Graf mini	mattsvart	370226-11		10	10	33	7316180008143	<b>47</b>
Knopp Graf mini	rostfri look	370227-11		10	10	33	7316180011198	<b>45</b>
Knopp Haga	mp pol.obeh	359411-11		21	21	30	7316183594117	<b>100</b>
Knopp Haga	mp.pol	359412-11		21	21	30	7316183594124	<b>100</b>
Knopp Helix	matt svart	309025-11		20	20	25	7316180003254	<b>89</b>
Knopp Helix	rf-look	309026-11		20	20	25	7316180003261	<b>89</b>
Knopp Helix	antik brons	309027-11		20	20	25	7316180003278	<b>106</b>
Knopp Helix	mässing	309028-11		20	20	25	7316180005807	<b>106</b>
Knopp Helix Stripe	matt svart	309201-11		20	20	25	7316180019262	<b>85</b>
Knopp Helix Stripe	antik brons	309202-11		20	20	25	7316180018609	<b>105</b>
Knopp Helix Stripe	mässing	309203-11		20	20	25	7316180018616	<b>105</b>
Knopp Helix Stripe	rf-look	309204-11		20	20	25	7316180019279	<b>85</b>
Knopp T Helix	matt svart	308570-11		60	16	35	7316180018661	<b>130</b>
Knopp T Helix	antik brons	308571-11		60	16	35	7316180018678	<b>150</b>
Knopp T Helix	mässing	308572-11		60	16	35	7316180018685	<b>150</b>
Knopp T Helix	rf-look	308573-11		60	16	35	7316180018692	<b>130</b>
Knopp T Helix Stripe	matt svart	309210-11		60	16	35	7316180018623	<b>120</b>
Knopp T Helix Stripe	antik brons	309211-11		60	16	35	7316180018630	<b>140</b>
Knopp T Helix Stripe	mässing	309212-11		60	16	35	7316180018647	<b>140</b>
Knopp T Helix Stripe	rf-look	309213-11		60	16	35	7316180018654	<b>120</b>
Knopp Hexa- 24	mattsvart	352000-11		24	28	24	7316180020916	<b>213</b>
Knopp Hexa- 24	rf-look	352001-11		24	28	24	7316180020923	<b>213</b>
Knopp T uniform	mässing	343295-11						
Knopp Lily	krom	304065-11		30	30	40	7316180010320	<b>48</b>
Knopp Lily	svart	304067-11		30	30	40	7316180010344	<b>45</b>
Knopp Lily	rf-look	304066-11		30	30	40	7316180010337	<b>48</b>
Knopp Lund	rostfri look	339418-11		25	25	21	7316183394182	<b>43</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Knopp Lund	krom	339419-11		25	25	21	7316183394199	<b>43</b>
Knopp Manor T	mässing antik	351030-11		54		39	7316180018357	<b>163</b>
Knopp Manor T	matt svart	351031-11		54		39	7316180018364	<b>163</b>
Knopp Manor Round	mässing antik	351035-11		30		35	7316180018371	<b>138</b>
Knopp Manor Round	matt svart	351036-11		30		35	7316180018388	<b>138</b>
Knopp Mood	mattsvart	370002-11		18	18	20	7316180008013	<b>44</b>
Knopp Mood	mattsvart	370006-11		18	18	30	7316180008020	<b>54</b>
Knopp Mood	mattsvart	370012-11		30	30	25	7316180008037	<b>106</b>
Knopp Mood	mattsvart	370016-11		30	30	50	7316180008044	<b>158</b>
Knopp Mood	mattb.mässing	370003-11		18	18	20	7316180011952	<b>69</b>
Knopp Mood	mattb.mässing	370007-11		18	18	30	7316180011969	<b>80</b>
Knopp Mood	mattb.mässing	370013-11		30	30	25	7316180011976	<b>140</b>
Knopp Mood	mattb.mässing	370017-11		30	30	50	7316180011983	<b>140</b>
Knopp Mood	mässing pol.	370001-11		20	18		7316183700013	<b>74</b>
Knopp Mood	mässing pol.	370005-11		30	18		7316183700051	<b>86</b>
Knopp Mood	mässing pol.	370011-11		25	30		7316183700112	<b>150</b>
Knopp Mood	mässing pol.	370015-11		50	30		7316183700150	<b>193</b>
Knopp Mushroom	ek obeh	255620-11		50	50	29	7316180008433	<b>70</b>
Knopp Mushroom	ek obeh	255625-11		65	65	29	7316180008440	<b>86</b>
Knopp Mushroom	björk obeh	255621-11		50	50	29	7316180008457	<b>65</b>
Knopp Mushroom	björk obeh	255626-11		65	65	29	7316180008464	<b>88</b>
Knopp Mynta	svart	308635-11		32	32	30	7316180013543	<b>78</b>
Knopp Mynta	pol.nickel	308636-11		32	32	30	7316180013550	<b>85</b>
Knopp Olle-30	obeh.ask	207005-11		30,5	30,5	30	7316180020855	<b>138</b>
Knopp Olle-30	obeh.ek	207006-11		30,5	30,5	30	7316180020862	<b>173</b>
Knopp Olympia	svart	25553-11		50	50	20	7316180008327	<b>114</b>
Knopp Olympia	ek	25551-11		50	50	20	7316182555102	<b>118</b>
Knopp Olympia	valnöt	25552-11		50	50	20	7316182555201	<b>110</b>
Knopp Orbit-36	mattsvart	352015-11		36	22	36	7316180021005	<b>323</b>
Knopp Orbit-36	ss-look	352016-11		36	22	36	7316180021012	<b>323</b>
Knopp Pitch	matt svart	309060-11		60	10	35	7316180003285	<b>152</b>
Knopp Pitch/bricka	matt svart	309110-11		60	10		7316180005979	<b>213</b>
Knopp Plato	borstad mattsvart	370204-11		42	42	24	7316180008747	<b>143</b>



Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Knopp Plato	borstad mässing	370206-11		42	42	24	7316180008761	<b>143</b>
Knopp Plato	rostfri look	370205-11		42	42	24	7316180008754	<b>140</b>
Knopp Plato OceanIX-32	mattsvart	352050-11		42	42	24	7316180021142	<b>238</b>
Knopp Rillan	bok	2006-11		44	44	34	7316182006000	<b>28</b>
Knopp Rillan	ek	2002-11		44	44	34	7316182002002	<b>30</b>
Knopp Rillan	vit	2005-11		44	44	34	7316182005003	<b>28</b>
Knopp Rillan 5-p	vit	2005-15		44	44	34	7316185300389	<b>111</b>
Knopp Rillan 5-p	bok	2006-15		44	44	34	7316185300396	<b>103</b>
Knopp Rillan 5-p	ek	2002-15		44	44	34	7316185300419	<b>103</b>
Knopp Rut-27	obeh.ask	207000-11		27	27	23	7316180020831	<b>123</b>
Knopp Rut-27	obeh.ek	207001-11		27	27	23	7316180020848	<b>163</b>
Knopp Scope	rostfri look	370185-11		16	16	30	7316180008624	<b>76</b>
Knopp Scope	svart	370186-11		16	16	30	7316180008631	<b>76</b>
Knopp Simon-35	mattsvart	352070-11		35	35	29	7316180021210	<b>323</b>
Knopp Simon-35	rf-look	352071-11		35	35	29	7316180021227	<b>323</b>
Knopp Solliden	matt svart	339432-11		25	25	27	7316180001021	<b>120</b>
Knopp Solliden	förnicklad	339430-11		25	25	27	7316181001808	<b>120</b>
Knopp Solliden	mässing pol	339431-11		25	25	27	7316181001907	<b>120</b>
Knopp Solliden	mässing pol obeh	339433-11		25	25	27	7316180018241	<b>120</b>
Knopp Sture	mässing obeh	339380-11		28	28	23	7316180014519	<b>90</b>
Knopp Sture	mässing	339381-11		28	28	23	7316180018166	<b>90</b>
Knopp Sture	förnicklad	339382-11		28	28	23	7316180018173	<b>90</b>
Knopp Sture	matt svart	339383-11		28	28	23	7316180018180	<b>90</b>
Knopp SP 5/30	vit/krom	4896-11		30	30	27	7316184896005	<b>46</b>
Knopp SP 5/30	vit/mp	48973-11		30	30	27	7316184897309	<b>46</b>
Knopp SS-F	rostfritt stål	36151-11		20	20	28	7316183615102	<b>76</b>
Knopp SS-G	rostfritt stål	36141-11		25	25	22	7316183614105	<b>83</b>
Knopp T-type	rf-look	343290-11		53	14	38	7316180017381	<b>73</b>
Knopp T-type	mattsvart	343291-11		53	14	38	7316180017398	<b>73</b>
Knopp T-type	mattvit	343292-11		53	14	38	7316180017404	<b>73</b>
Knopp T uniform	mässing	343295-11		50	10	36	7316180020633	<b>398</b>
Knopp T uniform	förnicklad	343296-11		50	10	36	7316180020640	<b>398</b>
Knopp T uniform	borstad mässing c	343297-11		50	10	36	7316180020657	<b>398</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Knopp T uniform	matt black	343298-11		50	10	36	7316180020664	<b>398</b>
Knopp T Graf mini	mässing	370250-11		60	10	33	7316180011280	<b>93</b>
Knopp T Graf mini	svart	370251-11		60	10	33	7316180011297	<b>93</b>
Knopp T Graf mini	rostfri look	370252-11		60	10	33	7316180011303	<b>93</b>
Knopp Torp	mp pol.obeh	359401-11		25	25	25	7316183594018	<b>106</b>
Knopp Torp	mp pol	359402-11		25	25	25	7316183594025	<b>106</b>
Knopp Transit-16	rf-look	352060-11		24	24	31	7316180021173	<b>173</b>
Knopp Transit-16	mattsvart	352061-11		24	24	31	7316180021180	<b>173</b>
Knopp Trumpet	obeh. ek	255660-11		38	38	23	7316180013338	<b>75</b>
Knopp Trumpet	svart	255661-11		38	38	23	7316180013345	<b>75</b>
Knopp Trumpet	obeh. ek	255665-11		48	48	29	7316180013352	<b>85</b>
Knopp Trumpet	svart	255666-11		48	48	29	7316180013369	<b>85</b>
Knopp Tuba	ek	255650-11		28	28	19	7316180013284	<b>70</b>
Knopp Tuba	svart	255651-11		28	28	19	7316180013291	<b>70</b>
Knopp Tuba	valnöt	255652-11		28	28	19	7316180013307	<b>85</b>
Knopp Wok	ek/vit	25501-11		50	50	20	7316182550107	<b>93</b>
Knopp Wok	ek/vit	25511-11		64	64	20	7316182551104	<b>113</b>
Knopp/platta 25568	förnicklad	39622-11		46	25		7316183962206	<b>81</b>
Loop	svart/mässing	333121-11		65	25		7316183331217	<b>118</b>
Loop	svart/koppar	333122-11		65	25		7316183331224	<b>118</b>
Loop	svart/pol.krom	333123-11		65	25		7316183331231	<b>118</b>
Loop	svart/svart	333124-11		65	25		7316180000963	<b>118</b>
Loop	brun/mässing	333131-11		65	25		7316183331316	<b>118</b>
Loop	brun/koppar	333132-11		65	25		7316183331323	<b>118</b>
Loop	brun/pol.krom	333133-11		65	25		7316183331330	<b>118</b>
Loop	brun/svart	333134-11		65	25		7316180000970	<b>118</b>
Loop	natur/mässing	333141-11		65	25		7316183331415	<b>118</b>
Loop	natur/koppar	333142-11		65	25		7316183331422	<b>118</b>
Loop	natur/pol.krom	333143-11		65	25		7316183331439	<b>118</b>
Loop	natur/svart	333144-11		65	25		7316180000987	<b>118</b>
Loop Round	svart/mässing	333221-11		70	25		7316180000277	<b>126</b>
Loop Round	svart/koppar	333222-11		70	25		7316180000284	<b>126</b>
Loop Round	svart/pol.krom	333223-11		70	25		7316180000291	<b>126</b>
Loop Round	svart/svart	333224-11		70	25		7316180002363	<b>126</b>
Loop Round	brun/mässing	333231-11		70	25		7316180000307	<b>126</b>

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Loop Round	brun/koppar	333232-11		70	25		7316180000314	126
Loop Round	brun/pol.krom	333233-11		70	25		7316180000321	126
Loop Round	svart/svart	333234-11		70	25		7316180002400	126
Loop Round	natur/mässing	333241-11		70	25		7316180000338	126
Loop Round	natur/koppar	333242-11		70	25		7316180000345	126
Loop Round	natur/pol.krom	333243-11		70	25		7316180000352	126
Loop Round	natur/svart	333244-11		70	25		7316180002424	126
Loop Strap	svart/mässing	333301-11		160	30	45	7316180001144	226
Loop Strap	svart/koppar	333302-11		160	30	45	7316180001151	226
Loop Strap	svart/pol.krom	333303-11		160	30	45	7316180001168	226
Loop Strap	svart/svart	333304-11		160	30	45	7316180001175	226
Loop Strap	brun/mässing	333305-11		160	30	45	7316180001182	226
Loop Strap	brun/koppar	333306-11		160	30	45	7316180001199	226
Loop Strap	brun/pol.krom	333307-11		160	30	45	7316180001205	226
Loop Strap	brun/svart	333308-11		160	30	45	7316180001212	226
Loop Strap	natur/mässing	333309-11		160	30	45	7316180001229	226
Loop Strap	natur/koppar	333310-11		160	30	45	7316180001236	226
Loop Strap	natur/pol.krom	333311-11		160	30	45	7316180001243	226
Loop Strap	natur/svart	333312-11		160	30	45	7316180001250	226
Profil Edge Filigree	rf-look	304190-11		60	45	21	7316180003650	135
Profil Edge Filigree	antik brons	304191-11		60	45	21	7316180003667	135
Profil Edge Straight	borst mässing	304163-11		40	40,9	18	7316180001267	63
Profil Edge Straight	rostfri look	303831-11		40	41	18	7316180001274	54
Profil Edge Straight	borst koppar	304164-11		40	41	18	7316180001281	63
Profil Edge Straight	borst antracit	304162-11		40	41	18	7316180001298	63
Profil Edge Straight	antik brons	304161-11		40	41	18	7316180001304	64
Profil Edge Straight	borst mässing	304168-11		200	41	18	7316180001311	138
Profil Edge Straight	rostfri look	304165-11		200	41	18	7316180001328	128
Profil Edge Straight	borst koppar	304169-11		200	41	18	7316180001335	131
Profil Edge Straight	borst antracit	304167-11		200	41	18	7316180001342	138
Profil Edge Straight	antik brons	304166-11		200	41	18	7316180001359	149
Profil Edge Straight	rostfri look	304170-11		350	41	18	7316180001366	184
Profil Edge Straight	antik brons	304171-11		350	41	18	7316180001373	212
Profil Edge Straight	borst mässing	304173-11		350	41	18	7316180001380	190
Profil Edge Straight	borst koppar	304174-11		350	41	18	7316180001397	181
Profil Edge Straight	borst antracit	304172-11		350	41	18	7316180001403	190
Profil Edge Straight	borst svart	304155-11		40	41	18	7316180003940	64
Profil Edge Straight	borst svart	304156-11		200	41	18	7316180003957	138
Profil Edge Straight	borst svart	304157-11		350	41	18	7316180003964	187
Profil Edge Straight	vit	304153-11		40	41	18	7316180006538	86
Profil Edge Straight	vit	304154-11		200	41	18	7316180006545	190

Benämning	Utförande	Art.nr.	c/c	L	B	D	EAN	Pris/st
Profil Edge Straight	vit	304076-11		350	41	18	7316180012980	<b>203</b>
Pushbricka Habit	borstad mässing	450200-11		50	30	4	7316180016520	<b>85</b>
Pushbricka Habit	rf-look	450201-11		50	30	4	7316180016537	<b>85</b>
Pushbricka Habit	borstad antracit	450202-11		50	30	4	7316180016544	<b>85</b>
Pushbricka Habit	matt svart	450203-11		50	30	4	7316180016551	<b>85</b>
Ring 106	antik	3904-11		41	41	11	7316183904008	<b>69</b>
Ring 157	antik	3910-11		33	39	12	7316183910009	<b>44</b>
Skålhandtag 1843	mässing	3870-11		95	40	20	7316183870006	<b>189</b>
Skålhandtag 1843	förnicklad	3872-11		95	40	20	7316183872000	<b>186</b>
Skålhandtag 1843	mässing obeh.	3873-11		95	40	20	7316180018586	<b>195</b>
Skålhandtag Care 3922	rf-look	39225C-11	64	95	36	19	7316180018111	<b>78</b>
Skålhandtag Care 3922	matt svart	39226C-11	64	95	36	19	7316180018128	<b>78</b>
Skålhandtag Newport	pol nickel	397241-11	96	107	23	18	7316183972410	<b>73</b>
Skålhandtag Timjan	svart	308630-11		105	27	23	7316180013529	<b>90</b>
Skålhandtag Timjan	pol.nickel	308631-11		105	27	23	7316180013536	<b>105</b>
Skålhandtag Toronto	krom	30470-11	64	90	25	29	7316183047002	<b>73</b>
Skålhandtag Toronto	rostfri look	30471-11	64	90	25	29	7316183047101	<b>73</b>
Skålhandtag Toronto	krom	30480-11	96	122	25	29	7316183048009	<b>93</b>
Skålhandtag Toronto	rostfri look	30481-11	96	122	25	29	7316183048108	<b>93</b>
Skålhtg 2532	rostfri look	38750-11	64	80	35	26	7316183875001	<b>90</b>
Skålhtg 2532	tennoxid	38753N-11	64	80	35	26	7316183875308	<b>57</b>
Skålhtg 3922	mässing matt	39223-11	64	95	38	19	7316183922309	<b>113</b>
Skålhtg 3922	pol.koppar	39221-11	64	95	38	19	7316183922101	<b>113</b>
Skålhtg 3922	mässing	3923-11	64	95	38	19	7316183923009	<b>113</b>
Skålhtg 3922	rostfri look	39225-11	64	95	38	19	7316183922507	<b>73</b>
Skålhtg 3922	antik	3922-11	64	95	38	19	7316183922002	<b>64</b>
Skålhtg 3922	förnicklad	39222-11	64	95	38	19	7316183922200	<b>73</b>
Skålhtg 3922	tenn	3924-11	64	95	38	19	7316183924006	<b>61</b>
Skålhtg 3922	antik svart	39224-11	64	95	38	19	7316183922408	<b>73</b>
Skålhtg 3922 5-p	tenn	3924-15	64	95	38	19	7316185300242	<b>238</b>
Skålhtg 4010	rostfri look	3049-11	64	92	40	25	7316183049006	<b>44</b>
Skålhtg 420	antik	3915-11	32	98	35	19	7316183915004	<b>69</b>

<b>Benämning</b>	<b>Utförande</b>	<b>Art.nr.</b>	<b>c/c</b>	<b>L</b>	<b>B</b>	<b>D</b>	<b>EAN</b>	<b>Pris/st</b>
Skålhtg 420	förnicklad	3916-11	32	98	35	19	7316183916001	<b>69</b>
Skåpsregel 5181U "ticka"	rostfritt	397955-11		55	45	26	7316183979556	<b>264</b>