



Lightweight and Portable Jeep Hardtop Removal System



How to use the
RollnJack



RollnJack
Assembly



For more
products
please visit



RollnJack Youtube
Channel

PLEASE READ ALL INSTRUCTIONS AND WATCH RELATED VIDEOS BEFORE ASSEMBLY AND USE OF THE ROLLN JACK

WARNING:

1. Please take necessary caution when assembling the RollnJack lift
2. It is necessary to attach the 5th safety arm top post AFTER removing the hardtop (for 4 door models only/not 2 door models). FAILURE TO DO SO COULD RESULT IN INJURY
3. Make sure the wheels are locked and the RollnJack is in a secure space during storage
4. Do not store the RollnJack outdoors
5. Keep children away from the RollnJack lift when in storage
6. Use the RollnJack lift on level ground with a smooth surface. A slight incline or decline can be acceptable. Store on level ground
7. NEVER – Push on the hardtop itself with your hands. All movement of the hardtop should be done via the RollnJack. Make sure the RollnJack is 100% clear of your jeep back before wheeling out

USAGE INSTRUCTIONS:

- Remove both (2) Jeep Freedom Panels
- Unscrew bolts on each side of hardtop near and above driver and passenger seats
- Open cargo door and lift rear window ajar completely
- Unscrew 6 Torx bolts that fasten hardtop in cargo area
- Detach electrical connection on driver side
- Wheel the RollnJack into the center of the rear cargo area; make sure the 4 top posts clear under window frame ridge. At this time the 5th support arm should not be attached to the RollnJack
- Turn the Easy Handle until the 4 top posts engage the hardtop and make sure they are secure. Turn the Easy Handle until you lift enough to clear the entire Jeep structure. Note: the jack is a self breaking lift mechanism so you can let go of the handle at any time and it will not drop/lower
- NOTE: The lifting posts can be arranged to different heights if your hardtop interior is not flat. It is best that when you start to lift your hardtop that it is lifted evenly
- Lift enough so that the bottom of the alignment posts clear the rear gate when rolling the RollnJack backwards
- The RollnJack can be stored with the Jeep top on, lower the height of the jack for extra stability

RETURN INSTRUCTIONS


If you have questions or would like to make a return/need replacement parts please contact us first, we are more than happy to provide support. Leave us a message with your name and order number and we will solve your issue and make things right! We will get back to you as soon as possible

We are best reached by email: help@rollnjack.com

For returns **PLEASE attach the return sticker provided in this box**


THE ROLLNJACK ASSEMBLY INSTRUCTION

A




M8x60 **(8X)**

B




M8-Flat **(8X)**

C




M8-Lock **(8X)**

E




M10x90 **(6X)**

F




M10-Flat **(6X)**

G




M10-Lock **(6X)**

I




Ø8x60-Pin **(5X)**

D




M8-Nut **(8X)**

H



M10-Nut **(6X)**


1



SWIVEL WHEEL

LOCK SWIVEL WHEEL

2




If the holes are not aligned and you can't get the bolts through, don't worry. Please troubleshoot by rotating the jack handle. When rotating the jack handle the holes inside the tube will align allowing for you to properly insert the bolts.


For an instructional video please scan the QR code below or go to www.rollnjack.com to see the troubleshooting video in the FAQ section.

Please scan me.


3




4



5



6



OK



Warranty

RollnJack warrants your product to be free from defects in metal tube materials and workmanship for lifetime from original date of shipment delivery to the address provided at checkout. All moving parts are covered under warranty for a period of twelve months. If you discover a defect in a product covered by this warranty, we will repair or replace the part(s) with new part(s). If repair is not possible, we will replace the item.

Exclusions

This warranty applies only to the original purchaser of the item. We do not cover warranty claims nor offer product warranties for items that were purchased by any persons other than the original purchaser.

This warranty covers defects in manufacturing discovered while using the product as recommended by the manufacturer. The warranty does not cover loss from theft, nor does coverage extend to damage caused by misuse, abuse, unauthorized modification, improper storage conditions, weather, or natural disasters. This warranty does not cover parts subject to normal wear and tear replacement requirements, such as caster wheels worn from constant use.

RollnJack will not be held liable to you or any other party for any damages incurred as a result from improper use and subsequent failure of this product. Damages excluded from this warranty include, but are not limited to: damage to vehicle, other equipment, dwelling, and incidental or consequential damages arising from the use, or inability to use this product. Should this product fail, your sole recourse shall be repair or replacement, as described in this warranty statement. In no way will RollnJack be liable for more than the purchase price of your product, not to exceed the current list price, and excluding tax and shipping and handling charges.

RollnJack disclaims any other warranties, express or implied.

How To Obtain Service Under This Warranty

Please complete your warranty signup on our website at rollnjack.com/warranty

or scan



Your warranty is valid once you complete the form and you confirm that you are the original purchaser of the item.