



# Accessories for 15 mm Connector

## Speaking Valves




REF 650-T

TRACOE phon assist I




REF 655-T

TRACOE phon assist II



REF 650-TO


TRACOE phon assist I  
with oxygen supply port



REF 650-TO-C

TRACOE phon assist I  
in a bright colour and  
with oxygen supply port

## Occlusion Cap




REF 516

TRACOE *modular* Occlusion Cap


Products listed here are intended exclusively for use with fenestrated tracheostomy tubes with a 15 mm connector. If a cuffed tube is being used, the cuff must be deflated before a speaking valve or occlusion cap is attached.

## Heat/Moisture Exchangers, HME




REF 640-CT

TRACOE humid assist I



REF 641

TRACOE humid assist III



REF 642

TRACOE humid assist IV




REF 643

TRACOE humid assist *kids*



## 22 mm Housing Adapter




REF 622

TRACOE *modular*  
22 mm Housing Adapter


# Accessories for 22 mm Housing

## Speaking Valves




**REF 650-S**

**TRACOE phon assist I**



**REF 650-SO**


**TRACOE phon assist I  
with oxygen supply port**



**REF 655-S**

**TRACOE phon assist II**

## Stopper




**REF 621**

**TRACOE modular stopper**

**Caution: Not for use with adhesive carrier  
REF 660!**

All the speaking valves and occlusion caps illustrated here can be fitted to fenestrated short silicone tubes, tracheostomy tubes, stoma and grid buttons, and the adhesive carrier with 22 mm housing.


## Heat/Moisture Exchanger, HME



**REF 640-S**


**TRACOE humid assist I**

## Heat/Moisture Exchanger, HME for Speaking Valve REF 655-T and REF 655-S




**REF 645**


**TRACOE humid assist II**



**REF 655-T**



**REF 655-S**



**REF 645**

This heat/moisture exchanger is intended exclusively for use with the hands-free speaking valves REF 655-T and REF 655-S.