


## Volunteer Landing Power Locations & Parking Spaces



1. City Box = 100 amp with multiple outlets
2. Bat Lights (columns on either side of Dock) = 20 amps per column with 2-110 volt outlets per column
3. VL Dock = 50 amp disconnect for boat hook-up only
4. VL Tower = 20 amps per pole with 3-110 volt outlets on 1st level & 5-110 volt outlets on 2nd level balcony
5. Pump House = 100 amp disconnect
6. Grassy Circle = 100 amp disconnect

- A. 3-parking spaces + 1-space that holds a Recycling Dumpster)
- B. 6-parking spaces
- C. 5-parking spaces + 2-ADA parking spaces

Please avoid driving across front of the VL Tower  
(denoted by red arrows)