

PRINTER TEST CARD INSTRUCTIONS

Step 1. Unlock the printer using the keys sent. The lock is on the left side of the printer.

Step 2. Please insert the cards oriented like the picture below-- The end with the chip facing the back of the printer, and the VISA logo facing up:





Step 3: Install ribbon and sticky roller:








Step 4: Close the front door and lock the printer.

Step 5: On the Brightwell Windows PC, use the following login:

Username: OP_User Password: Oceanpay1\$

Once logged in, you will be brought to a desktop with the following icons on it:






Step 6: Click on "Cardwizard Production Queue Client" and log in using the Cardwizard credentials sent to you.

If you do not have credentials, please send an email to itops@brightwell.com with your first and last name and we will create one for you.

Once you have logged in, you will see the following screen:



Step 7: Click to select a card to print, and then click on "Make Card". If card machine shows "none", please make sure it says "ready" on the front. The printer will be put in a suspended mode if left open or unlocked.

If you have any questions, please don't hesitate to ask!