

I'm not a bot



Blackweb bluetooth speaker bwa18aa013 manual

Blackweb bwa18av003 bluetooth transmitter manual. Blackweb bwa18aa014 manual. Blackweb bluetooth speaker instructions. Blackweb speaker instructions.

Power button: Press and hold for 2 seconds to turn device ON/OFF. VOLUME UP +: Short press to increase volume, long press (2s) to skip next track. VOLUME DOWN -: Short press to decrease volume, long press (2s) to go back to previous track. Indicator light: - Power ON: Solid blue light for 1 second. - Bluetooth pairing: Flashing blue and red light until paired, then solid blue. - Power OFF: Solid blue light for 1 second, then off. - Charging: Solid red light until fully charged, then turns off. To pair speaker: 1. Ensure device has Bluetooth. 2. Turn on speaker (hold power button for 2 seconds) and look for blinking light. 3. Find "Blackweb RGD A011" in device's Bluetooth list and click YES to connect. Auto off: Speaker will turn off after 2 minutes if not connected, or 15 minutes of pause after pairing. To disconnect: Long press the Bluetooth button up to 3 seconds to enter pairing mode. For call handling: - Answer call: Short press PLAY/PAUSE. - Hang up: Short press PLAY/PAUSE. - Move call from speaker to device: Long press PLAY/PAUSE for 3s. - Reject incoming call: Long press PLAY/PAUSE for 3s. To unplug two speakers, hold down both the "+" and "-" buttons at the same time for up to 2 seconds. AUX-CABLE MODE: First, plug one end of the cord into the speaker and the other into your device's headphone jack. Next, turn on the speaker and hit play on your device. Note that if you're in PARTY MODE with an aux cable, music will only come from the device it's connected to. For USB connections, a 25cm Micro USB cable is used along with the BWA18AA011 USB Charging Port which can charge at up to 2000mA. The PLAY/PAUSE button controls several functions: short press turns volume up or down, hold for 3 seconds skips forward or backward in tracks. The indicator light shows different statuses - it's solid blue when turned on momentarily, then flashing blue and red while pairing, turning off once paired. It flashes red during charging, then turns off once full. To pair the speaker: ensure your device has Bluetooth, turn on the speaker (hold PLAY/PAUSE for 3 seconds), and look for Blackweb SPRK A010 in your device's list. Auto-off feature shuts down speakers not connected to Bluetooth after 2 minutes, and pauses automatically if no music is played for 15 minutes or more. To disconnect from a device, press "+" and "-" buttons together for up to 4 seconds to enter Pairing mode. For call handling: short press PLAY/PAUSE button to answer an incoming call, hang up by short pressing again. Move the call from speaker to device by long pressing PLAY/PAUSE during a call. To ignore an incoming call, press the play/pause button for 3 seconds. The following table provides details: | Situation | USB Cable | Bluetooth Speaker | | -- | -- | -- | | First Incoming Call | - | Short Press: Pick up call; Long Press: Reject call | | On Call | - | Short Press: Move call to device; Long Press: End call | | 25 cm Micro USB cable | Connect device | - | | BWA18AA010 (device) | - | - | | BWA18AA010 (speaker) | - | - |