



Precision-Fit Headrest Owner's Manual

Cleaning Instructions

Precision-Fit headrest covers can be machine washed, in cold water on the delicate cycle. Hang to dry.

If you have any questions regarding your headrest contact the vendor who provided it.

Mounting to Back Support

PRM Inc. does not attach the headrest to the seating system. Therefore, it is the responsibility of the vendor who provided your system to properly attach the headrest to the seating system. Mounting hardware should be checked by the end user daily to ensure hardware is securely attached. Discontinue use if hardware has loosened and/or is not properly attached. If you have any questions regarding your headrest contact the vendor who provided it.